

Installing and Administering HyperFabric

HP-UX 11i v1 and HP-UX 11i v2

Edition 13



Manufacturing Part Number: B6257-90060

October 2006

Printed in U.S.A.

© Copyright 2006 Hewlett-Packard Company.

Legal Notices

The information in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be held liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Warranty. A copy of the specific warranty terms applicable to your Hewlett-Packard product and replacement parts can be obtained from your local Sales and Service Office.

U.S. Government License

Proprietary computer software. Valid license from HP required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Copyright Notice

Copyright © 2003-2006 Hewlett-Packard Development Company L.P. All rights reserved. Reproduction, adaptation, or translation of this document without prior written permission is prohibited, except as allowed under the copyright laws.

Trademark Notices

Oracle ® is a registered trademark of Oracle Corporation.

UNIX® is a registered trademark in the United States and other countries, licensed exclusively through The Open Group.

1. Overview

Overview	15
HyperFabric Products	16
HyperFabric Adapters	16
Switches and Switch Modules	17
Other Product Elements	18
HyperFabric Concepts	19

2. Planning the Fabric

Preliminary Considerations	23
HyperFabric Functionality for TCP/IP and HMP Applications	24
TCP / IP	25
Application Availability	25
Features	25
Configuration Parameters	28
TCP/IP Supported Configurations	32
Point-to-Point Configurations	32
Switched	34
High Availability Switched	35
Hybrid	36
Mixed HF1 / HF2 (Copper & fibre)	37
Hyper Messaging Protocol (HMP)	38
Application Availability	38
Features	38
Configuration Parameters	40
HMP Supported Configurations	43
Point to Point	43
Enterprise (Database)	45
Technical Computing (Work Stations)	48

3. Installing HyperFabric

Checking HyperFabric Installation Prerequisites	53
Installing HyperFabric Adapters	54
Online Addition and Replacement—HP-UX 11i Only	55
Planning and Preparation	57
Critical Resources	57
Card Compatibility	57
Online Addition (OLA)	57
Online Replacement (OLR)	58
Installing the Software	60
File Structure	60
Loading the Software	64
Installing HyperFabric Switches	66
Before Installation	66
Steps for Installing the HF1 Switch	68
Installing the HF2 Switch	76

Contents

With the Rail Kit	78
Installing the HF2 Switch With the Rail kit	78
Without the Rail Kit	81
4. Configuring HyperFabric	
Configuration Overview	85
Information You Need	86
Configuration Information Example	88
Doing the Configuration	91
Using the clic_init Command	92
Examples of clic_init	93
Using SAM—HP-UX 11.0 and HP-UX 11i	94
Deconfiguring a HyperFabric Adapter with SAM—HP-UX 11.0 and 11i Only	96
Configuring the HyperFabric EMS Monitor	97
Configuring HyperFabric with MC/ServiceGuard	98
How HyperFabric Handles Adapter Failures	100
Configuring HyperFabric with the MC/ServiceGuard Resource Monitor	104
Configuring MC/ServiceGuard with HyperFabric Using the ASCII File	105
Configuring MC/ServiceGuard with HyperFabric Using SAM	105
Configuring MC/ServiceGuard for HyperFabric Relocatable IP Addresses	106
5. Managing HyperFabric	
Starting HyperFabric	109
Using the clic_start Command	109
Using SAM—HP-UX 11.0 and 11i Only	110
Verifying Communications within the Fabric	111
The clic_probe Command	111
Examples of clic_probe	113
Displaying Status and Statistics	115
The clic_stat Command	115
Examples of clic_stat	116
Viewing man Pages	122
Stopping HyperFabric	123
Using the clic_shutdown Command	123
Using SAM—HP-UX 11.0 and 11i Only	124
6. Troubleshooting HyperFabric	
Running Diagnostics	127
The clic_diag Command	129
Example of clic_diag	131
Using Support Tools Manager	132
Useful Files	133
LED Colors and Their Meanings	135
Adapter LEDs	135
HF1 Switch LEDs	138
HF2 Switch LEDs	142

Determining Whether an Adapter or a Cable is Faulty	146
Determining Whether a Switch is Faulty	147
HF1 Switch	147
HF2 Switch	147
Replacing a HyperFabric Adapter	149
Replacing a HyperFabric Switch	150

HF1 Speed and Latency w/ TCP/IP Applications	30
HF2 Speed and Latency w/ TCP/IP Applications	30
Supported Configurations for A6386A HF2 Adapter On PCI (4X)	31
HF1 Speed and Latency w/ HMP Applications	41
HF2 Speed and Latency w/ HMP Applications	41
Supported Configurations for A6386A HF2 Adapter On PCI (4X)	42
Important OLAR Terms	56
LED Names (by Adapter)	135
HyperFabric Adapter LED Colors and Meanings	136
HF1 Switch LED Colors and Meanings	140
HF2 Switch LED Colors and Meanings	144

TCP/IP Point-To-Point Configurations	33
TCP/IP Basic Switched Configuration	34
TCP/IP High Availability Switched Configuration	35
TCP/IP Hybrid Configuration	36
TCP/IP Mixed HF1 & HF2 Configuration	37
HMP Point-To-Point Configurations	44
HMP Enterprise (Database) Configuration, Single Connection Between Nodes	46
HMP Enterprise (Database) Configuration, Multiple Connections Between Nodes	47
Technical Computing Configuration	49
Large Technical Computing Configuration	50
HyperFabric File Structure	60
Back of HF1 Switch	68
Front of HF2 Switch (A6388A Switch Module Installed)	76
Front of HF2 Switch (A6389A Switch Module Installed)	77
Parts of the Rail Kit	78
The Ends of the Rail Kit	79
Map for Configuration Information Example	88
An MC/ServiceGuard Configuration (with Two HyperFabric Switches)	100
Node with Two Active HyperFabric Adapters	102
Node with One Failed HyperFabric Adapter	103
When All HyperFabric Adapters Fail	104

Printing History

The manual printing date and part number indicate its current edition. The printing date will change when a new edition is printed. Minor changes may be made at reprint without changing the printing date. The manual part number will change when extensive changes are made.

Manual updates may be issued between editions to correct errors or document product changes. To ensure that you receive the updated or new editions, you should subscribe to the appropriate product support service. See your HP sales representative for details.

First Edition: March 1998

Second Edition: June 1998

Third Edition: August 1998

Fourth Edition: October 1998

Fifth Edition: December 1998

Sixth Edition: February 1999

Seventh Edition: April 1999

Eighth Edition: March 2000

Ninth Edition: June 2000

Tenth Edition: December 2000

Eleventh Edition: June 2001

Twelfth Edition: September 2002

Thirteenth Edition: March 2006

1 Overview

This chapter contains the following sections that give general information about HyperFabric:

- “Overview” on page 15
- “HyperFabric Products” on page 16

- “HyperFabric Concepts” on page 19

Overview

HyperFabric is a Hewlett-Packard high-speed, packet-based interconnect for node-to-node communications. HyperFabric provides higher speed, lower network latency and less CPU usage than other industry standard protocols (e.g. Fibre Channel and Gigabit Ethernet). Instead of using a traditional bus based technology, HyperFabric is built around switched fabric architecture, providing the bandwidth necessary for high speed data transfer. This clustering solution delivers the performance, scalability and high availability required by:

- Parallel Database Clusters:
 - Oracle 9i Real Application Clusters (RAC)
 - Oracle 8i Parallel Servers (OPS)
- Parallel Computing Clusters
- Client/Server Architecture Interconnects (e.g. SAP)
- Multi-Server Batch Applications (e.g. SAS Systems)
- Enterprise Resource Planning (ERP)
- Technical Computing Clusters
- Omniback
- Network Backup
- NFS
- Data Center Network Consolidation
- E-services

Oracle RAC10g Support Notice

HyperFabric product suite was designed to optimize performance of Oracle RAC9i database running on HP-UX clusters. With the industry moving to standards-based networking technologies for database clustering solutions, HP and Oracle have worked together to optimize features and performance of Oracle RAC10g database with standards-based interconnect technologies including Gigabit Ethernet, 10Gigabit Ethernet and Infiniband.

To align with the market trend for standards-based interconnects, Oracle RAC10g database is not currently supported on configurations consisting of HyperFabric product suite and it will not be supported in the future either. As a result, customers must switch to Gigabit Ethernet, 10Gigabit Ethernet or Infiniband technology if they plan to use Oracle RAC10g.

Please note that configurations comprising HyperFabric and Oracle 9i continue to be supported.

HyperFabric Products

HyperFabric hardware consists of host-based interface adapter cards, interconnect cables and optional switches. HyperFabric software resides in ASICs and firmware on the adapter cards and includes user space components and HP-UX drivers.

Currently both copper and fibre based HyperFabric hardware is available. There is also a hybrid switch that has 8 fibre ports and 4 copper ports to support mixed HF1 and HF2 clusters.

The various HyperFabric products are described below. See the *HP HyperFabric Release Note* for information about the HP 9000 systems these products are supported on.

NOTE

In this manual, the term HyperFabric (HF) is used in general to refer to the hardware and software that form the HyperFabric cluster interconnect product.

The term HyperFabric1 (HF1) refers to the copper based hardware components:

- The A4919A, A4920A, A4921A, and A6092A adapters.
- The A4891A switch.
- The A4892A cable.

The term HyperFabric2 (HF2) refers to the fibre based hardware components:

- The A6386A adapter.
 - The A6384A switch chassis.
 - The A6388A and A6389A switch modules. (Although the A6389A switch module has 4 copper ports it is still considered a HF2 component because it can only be used with the A6384A HF2 switch chassis).
 - The C7524A, C7525A, C7526A, and C7527A cables.
-

HyperFabric Adapters

The HyperFabric adapters include the following:

- A4919A HF1 PCI (1X) adapter with a copper interface. (Discontinued...04-02)
- A4920A HF1 HSC adapter with a copper interface. (Discontinued...09-02)
- A4921A HF1 EISA/HSC adapter with a copper interface. (Discontinued...09-02)
- A6092A HF1 PCI (4X) adapter with a copper interface.
- A6386A HF2 PCI (4X) adapter with a fibre interface.

The A4919A, A4920A, and A4921A HF1 adapters are supported beginning with the following HyperFabric software versions:

- HP-UX 10.20: HyperFabric software version B.10.20.02
- HP-UX 11.0: HyperFabric software version B.11.00.02
- HP-UX 11i: HyperFabric software version B.11.11.00

The A6092A HyperFabric adapter is supported beginning with the following HyperFabric software versions:

- HP-UX 10.20: HyperFabric software version B.10.20.09
- HP-UX 11.0: HyperFabric software version B.11.00.09
- HP-UX 11i: HyperFabric software version B.11.11.00

The A6386A HyperFabric2 adapter is supported beginning with the following HyperFabric software versions:

- HP-UX 11.0: HyperFabric software version B.11.00.11
- HP-UX 11i: HyperFabric software version B.11.11.01

Switches and Switch Modules

The HyperFabric1 and HyperFabric2 switches are as follows:

- A4891A HF1 16-port copper switch with an Ethernet port.
- A6384A HF2 fibre switch chassis with one integrated Ethernet management LAN adapter card, one integrated 8-port fibre card, and one expansion slot. For the chassis to be a functional switch, one of these two switch modules must be installed in the expansion slot:
 - The A6388A HF2 8-port fibre switch module. This gives the switch 16 fibre ports (8 from the integrated fibre card and 8 from the A6388A).
 - The A6389A HF2 4-port copper switch module. This gives the switch 12 ports—a mixture of 8 fibre ports (from the integrated fibre card) and 4 copper ports (from the A6389A module). This switch module is compatible with HF1 components making it possible to have a fabric composed of both HF1 and HF2 components.

The A4891A HF1 switch is supported beginning with the following HyperFabric software versions:

- HP-UX 10.20: HyperFabric software version B.10.20.02
- HP-UX 11.0: HyperFabric software version B.11.00.02
- HP-UX 11i: HyperFabric software version B.11.11.00

The A6384A HF2 switch chassis with either module installed is supported beginning with the following HyperFabric software versions:

- HP-UX 11.0: HyperFabric software version B.11.00.11
- HP-UX 11i: HyperFabric software version B.11.11.01

NOTE

In this manual, the terms HyperFabric2 switch or HF2 switch refer to the functional switch (the A6384A switch chassis with one of the switch modules installed).

IMPORTANT

HF1 and HF2 adapters and switches are not supported by software versions earlier than those listed in “HyperFabric Adapters” on page 16 and “Switches and Switch Modules” on page 17.

To determine the version of HyperFabric you have, issue this command:

```
swlist | grep -i hyperfabric
```

Other Product Elements

The other elements of the HyperFabric product family are the following:

- A4892A HF1 copper cable (in 35-foot and 60-foot lengths).
- HF2 fibre cables:
 - C7524A (2m length)
 - C7525A (16m length)
 - C7526A (50m length)
 - C7527A (200m length)
- The HyperFabric software: The software resides in ASICs and firmware on the adapter cards and includes user space components and HP-UX drivers.

HyperFabric supports the IP network protocol stack, specifically TCP/IP, UDP/IP, and NFS.

HyperFabric software includes HyperMessaging Protocol (HMP). HMP provides higher bandwidth, lower CPU overhead, and lower latency (the time it takes a message to get from one point to another). However, these HMP benefits are only available when applications that were developed on top of HMP are running. Note that HMP can only be used on HP 9000 systems running HP-UX 11.0 or 11i provided HyperFabric A6092A or A6386A (PCI 4X) adapter cards are installed on those systems.

In addition, running an HMP application disables a node's ability to interoperate with nodes that are using any HP-UX 10.20 version of HyperFabric, any HP-UX 11.0 HyperFabric versions earlier than B.11.00.11 or any HP-UX 11i HyperFabric versions earlier than B.11.11.01. If you use HMP on a node in the fabric, that node cannot communicate with any other nodes that are running the above versions of the HyperFabric software. See Chapter 2, "Planning the Fabric," on page 21 for details on using HMP applications in a HyperFabric cluster.

HyperFabric Concepts

Some basic HyperFabric concepts and terms are briefly described below.

The fabric is the physical configuration that consists of all of the HyperFabric adapters, the HyperFabric switches (if any are used) and the HyperFabric cables connecting them. The network software controls data transfer over the fabric.

A HyperFabric configuration contains two or more HP 9000 systems and optional HyperFabric switches. Each HP 9000 acts as a node in the configuration. Each node has a minimum of one and a maximum of eight HyperFabric adapters installed in it. (See Chapter 2, “Planning the Fabric,” on page 21 for information about the maximum number of adapters that can be installed in each system.) Each HF1 **switch** has 16 ports; each HF2 switch can be configured with 12 or 16 ports. HyperFabric supports a maximum of eight HyperFabric switches. HyperFabric switches can be meshed, and configurations with up to four levels of meshed switches are supported.

A HyperFabric cluster can be planned as a **High Availability (HA)** configuration, when it is necessary to ensure that each node can always participate in the fabric. This is done by using MC/ServiceGuard, MC/LockManager, and the Event Monitoring Service (EMS). Configurations of up to four nodes are supported under MC/ServiceGuard.

Beginning with HyperFabric software versions B.11.00.05 and B.11.11.00 (not HP-UX 10.20), **relocatable IP addresses** can be used as part of an HA configuration. Relocatable IP addresses permit a client application to reroute through an adapter on a remote node, allowing that application to continue processing without interruption. The rerouting is transparent. This function is associated with MC/ServiceGuard (see “Configuring MC/ServiceGuard for HyperFabric Relocatable IP Addresses” on page 106). When the monitor for HyperFabric detects a failure and the backup adapter takes over, the relocatable IP address is transparently migrated to the backup adapter. Throughout this migration process, the client application continues to execute normally.

When you start HyperFabric (with the `clie_start` command, through SAM [on HP-UX 11.0 or 11i only], or by booting the HP 9000 system), you start the **management process**. This process must be active for HyperFabric to run. If the HyperFabric management process on a node stops running for some reason (for example, if it is killed), all HyperFabric-related communications on that node are stopped immediately. This makes the node unreachable by other components in the fabric.

When you start HyperFabric, the fabric is, in effect, verified automatically. This is because each node performs a self diagnosis and verification over each adapter installed in the node. Also, the management process performs automatic routing and configuring for each switch (if switches are part of the fabric). You can, if you wish, run the `clie_stat` command to get a textual map of the fabric, which can be used as another quick verification.

You might notice that the commands you use to administer HyperFabric all have a prefix of `clie_`, and some of the other components have **CLIC** as part of their name (for example, the CLIC firmware and the CLIC software). CLIC stands for CLuster InterConnect, and it is used to differentiate those HyperFabric commands/components from other commands/components. For example, the HyperFabric command `clie_init` is different from the HP-UX `init` command.

2 Planning the Fabric

This chapter contains the following sections offering general guidelines and protocol specific considerations for planning HyperFabric clusters that will run TCP/IP or HMP applications.

- “Preliminary Considerations” on page 23

- “HyperFabric Functionality for TCP/IP and HMP Applications” on page 24
- “TCP / IP” on page 25
- “Hyper Messaging Protocol (HMP)” on page 37

Preliminary Considerations

Before beginning to physically assemble a fabric, follow the steps below to be sure all appropriate issues have been considered:

- Step 1.** Read Chapter 1, “Overview,” on page 13 to get a basic understanding of HyperFabric and its components.
- Step 2.** Read this chapter, *Planning the Fabric*, to gain an understanding of protocol specific configuration guidelines for TCP/IP and HMP applications.
- Step 3.** Read “Configuration Overview” on page 85, “Information You Need” on page 86, and “Configuration Information Example” on page 88, to gain an understanding of the information that must be specified when the fabric is configured. Keep these configuration requirements in mind while following the rest of the steps below to plan and map the fabric. (See Figure 4-1 for an example of a graphical fabric map.)
- Step 4.** Decide the number of nodes that will be interconnected in the fabric.
- Step 5.** Decide the type of HP 9000 system that each node will be (see the *HP HyperFabric Release Note* for a list of the supported HP 9000 systems).
- Step 6.** Determine the network bandwidth requirements for each node.
- Step 7.** Determine the number of adapters needed for each node.
- Step 8.** Determine if a High Availability (MC/ServiceGuard) configuration will be needed. Remember, If MC/ServiceGuard is used there must be at least two adapters in each node.
- Step 9.** Decide what the topology of the fabric will be.
- Step 10.** Determine how many switches will be used based on the number of nodes in the fabric. Remember, the only configuration that can be supported without a switch is the node-to-node configuration (HA or non-HA). HyperFabric supports meshed switches up to a depth of four switches, starting with these versions of the HyperFabric software:
 - For HF switches: software versions B.10.20.05, B.11.00.05, and B.11.11.00.
 - For HF2 switches: software versions B.11.00.11 and B.11.11.01.
- Step 11.** Draw the cable connections from each node to the switches (if the fabric will contain switches). If you will be using an HA configuration with switches, note that for full redundancy and to avoid a single point of failure, your configuration will require more than one switch. For example, each adapter can be connected to its own switch, or two switches can be connected to four adapters.

HyperFabric Functionality for TCP/IP and HMP Applications

The following sections in this chapter define HyperFabric features, parameters, and supported configurations for TCP/IP applications and Hyper Messaging Protocol (HMP) applications. There are distinct differences in supported hardware, available features and performance, depending on which protocol is used by applications running on the HyperFabric.

TCP / IP

TCP/IP is supported on all HF1 (copper) and HF2 (fibre) hardware. Although some of the HyperFabric adapter cards support both HMP and TCP/IP applications, our focus in this section will be on TCP/IP HyperFabric applications.

Application Availability

All applications that use the TCP/IP stack are supported, including Oracle 9i and HP-MPI.

NOTE

There are distinct differences between the feature set that is supported for TCP/IP and the feature set that is supported for HMP. Although TCP/IP and HMP applications are able to run simultaneously on the same HyperFabric cluster, for practical purposes, a HyperFabric cluster must run TCP/IP applications exclusively or HMP applications exclusively.

Features

- OnLine Addition and Replacement (OLAR): Supported

The OLAR feature allows the replacement or addition of HyperFabric adapter cards while the system (node) is running. HyperFabric supports this functionality on the rp54xx (L-class), rp74xx (N-class), rp8400 and Superdome systems, running on the HP-UX 11i platform with patch PHNE_25485.

For more detailed information on OLAR, including instructions for implementing this feature, see “Online Addition and Replacement—HP-UX 11i Only” on page 55 in this manual, as well as *Configuring HP-UX for Peripherals* Part Number B2355-90698 November 2000 Edition.

- Event Monitoring Service (EMS): Supported

Starting with the December 2000 releases B.11.00.11 and B.11.11.01, the HyperFabric EMS monitor allows the system administrator to separately monitor each HyperFabric adapter on every node in the fabric, in addition to monitoring the entire HyperFabric subsystem. The monitor can inform the user if the resource being monitored is UP or DOWN. The administrator defines the condition to trigger a notification (usually a change in interface status). Notification can be accomplished with a SNMP trap or by logging into the syslog file with a choice of severity, or by email to a user defined email address.

For more detailed information on EMS, including instructions for implementing this feature, see “Configuring the HyperFabric EMS Monitor” on page 97 in this manual, as well as the *EMS Hardware Monitors User's Guide* Part Number B6191-90028 September 2001 Edition.

- MC ServiceGuard: Supported

Within a cluster, MC/ServiceGuard groups application services (individual HP-UX processes) into packages. In the event of a single service failure (node, network, or other resource), EMS provides notification and MC/ServiceGuard transfers control of

the package to another node in the cluster, allowing services to remain available with minimal interruption. MC/ServiceGuard via EMS, directly monitors cluster nodes, LAN interfaces, and services (the individual processes within an application). MC/ServiceGuard uses a heartbeat LAN to monitor the nodes in a cluster. It is not possible to use HyperFabric as a heartbeat LAN. Instead a separate LAN must be used for the heartbeat.

For more detailed information on configuring MC ServiceGuard, see “Configuring HyperFabric with MC/ServiceGuard” on page 98 in this manual, as well as *Managing MC/ServiceGuard* Part Number B3936-90065 March 2002 Edition.

- **High Availability (HA): Supported**

To create a highly available HyperFabric cluster, there cannot be any single point of failure. Once the HP 9000 nodes and the HyperFabric hardware have been configured with no single point of failure, MC/ServiceGuard and EMS can be configured to monitor and fail-over nodes and services using ServiceGuard packages.

If any HyperFabric resource in a cluster fails (adapter card, cable or switch port), the HyperFabric driver transparently routes traffic over other available HyperFabric resources with no disruption of service.

The ability of the HyperFabric driver to transparently fail-over traffic reduces the complexity of configuring highly available clusters with MC/ServiceGuard, because MC/ServiceGuard only has to take care of node and service failover.

A “heartbeat” is used by MC/ServiceGuard to monitor the cluster. The HyperFabric links cannot be used for the heartbeat. Instead an alternate LAN connection (100BaseT, Ethernet, Token Ring, FDDI) must be made between the nodes for use as a heartbeat link.

End To End HA: HyperFabric provides End to End HA on the entire cluster fabric at the link level. If any of the available routes in the fabric fails, HyperFabric will transparently redirect all the traffic to a functional route and, if configured, notify MC/ServiceGuard or other enterprise management tools.

Active-Active HA: In configurations where there are multiple routes between nodes, the HyperFabric software will use a hashing function to determine which particular adapter/route to send messages through. This is done on a message-by-message basis. All of the available HyperFabric resources in the fabric are used for communication.

In contrast to Active-Passive HA, where one set of resources is not utilized until another set fails, Active-Active HA provides the best return on investment because all of the resources are utilized simultaneously. MC/ServiceGuard is not required for Active-Active HA operation.

For more information on setting up HA HyperFabric clusters, see figure 2-3 “TCP/IP High Availability Switched Configuration”.

- **Dynamic Resource Utilization (DRU): Supported**

When a new resource (node, adapter, cable or switch) is added to a cluster, a HyperFabric subsystem will dynamically identify the added resource and start using it. The same process takes place when a resource is removed from a cluster. The difference between DRU and OLAR is that OLAR only applies to the addition or replacement of adapter cards from nodes.

- **Load Balancing: Supported**

When a HP 9000 HyperFabric cluster is running TCP/IP applications, the HyperFabric driver balances the load across all available resources in the cluster including nodes, adapter cards, links, and multiple links between switches.

- **Switch Management: Not Supported**

Switch Management is not supported. Switch management will not operate properly if it is enabled on a HyperFabric cluster.

- **Diagnostics: Supported**

Diagnostics can be run to obtain information on many of the HyperFabric components via the `clic_diag`, `clic_probe` and `clic_stat` commands, as well as the Support Tools Manager (STM).

For more detailed information on HyperFabric diagnostics see “Running Diagnostics” on page 103 on page 149.

Configuration Parameters

This section details, in general, the maximum limits for TCP/IP HyperFabric configurations. There are numerous variables that can impact the performance of any particular HyperFabric configuration. See the “TCP/IP Supported Configurations” section for guidance on specific HyperFabric configurations for TCP/IP applications.

- HyperFabric is only supported on the HP 9000 series unix servers and workstations.
- TCP/IP is supported for all HyperFabric hardware and software.
- **Maximum Supported Nodes and Adapter Cards:**

In point to point configurations the complexity and performance limitations of having a large number of nodes in a cluster make it necessary to include switching in the fabric. Typically, point to point configurations consist of only 2 or 3 nodes.

In switched configurations, HyperFabric supports a maximum of 64 interconnected adapter cards.

A maximum of 8 HyperFabric adapter cards are supported per instance of the HP-UX operating system. The actual number of adapter cards a particular node is able to accommodate also depends on slot availability and system resources. See node specific documentation for details.

A maximum of 8 configured IP addresses are supported by the HyperFabric subsystem per instance of the HP-UX operating system.

- **Maximum Number of Switches:**

Up to 4 switches (16 port copper, 16 port fibre or Mixed 8 fibre ports / 4 copper ports) can be interconnected (meshed) in a single HyperFabric cluster.

- **Trunking Between Switches (multiple connections)**

Trunking between switches can be used to increase bandwidth and cluster throughput. Trunking is also a way to eliminate a possible single point of failure. The number of trunked cables between nodes is only limited by port availability. To assess the effects of trunking on the performance of any particular HyperFabric configuration, consult with your HP representative.

- **Maximum Cable Lengths:**

HF1 (copper): The maximum distance between two nodes or between a node and a switch is 60 ft. (2 standard cable lengths are sold and supported: 35 ft. and 60 ft.)

TCP/IP supports up to four HF1 switches connected in series with a maximum cable length of 60 ft. between the switches and 60 ft. between switches and nodes.

HF2 (fibre): The maximum distance is 200m (4 standard cable lengths are sold and supported: 2m, 16m, 50m and 200m).

TCP/IP supports up to four HF2 switches connected in series with a maximum cable length of 200m between the switches and 200m between switches and nodes.

TCP/IP supports up to 4 hybrid HF1/HF2 switches connected in series with a maximum cable length of 60 ft. between copper ports and 200m between fibre ports.

Speed and Latency:

Table 2-1 HF1 Speed and Latency w/ TCP/IP Applications

Server Class	Maximum Speed	Latency
rp7400	1.28 + 1.28 Gbps full duplex per link	< 50 microsec

Table 2-2 HF2 Speed and Latency w/ TCP/IP Applications

Server Class	Maximum Speed	Latency
rp7400	2 + 2 Gbps full duplex per link	< 42 microsec

Table 2-3 Supported Configurations for A6386A HF2 Adapter On PCI (4X)

Supported HP 9000 Systems	HP-UX Version	OLAR Support?	Maximum Adapters per System
rp24xx (A400 and A500)	11.0, 11i v1, 11iv2	No	2
rp34xx Series	11i v1 and 11i v2	No	2
rp44xx Series	11i v1 and 11i v2	Yes	4
rp54xx Series (L Class Servers)	11.0, 11i v1 and 11i v2	Yes (11iv1 and later)	2
rp74x0 (N-Class Series)	11.0, 11i v1 and 11i v2	Yes	8
rp84x0	11i v1 and 11i v2	Yes	8 (maximum 4 per PCI card cage)
rx16x0 Servers	11i v2	Yes	2
rx26x0 Servers	11i v2	No	2
rx4640 Servers	11i v2	Yes	4
rx56xx Series	11i v2	No	2
rx76x0 Servers	11i v2	No	8 (maximum 4 per PCI card cage)
rx86x0 Servers	11i v2	Yes	8 (maximum 4 per PCI card cage)
zx6000 Workstations	11i v2	No	1
B1000, B2000, B2600, C3000, C3600, C3700, J5000, J5600, J6000, J6700 and J7000 workstations	11.0, 11i v1	No	2
Superdome servers	11i v1 and 11i v2	Yes	8 (maximum 4 per PCI card cage)
SD64A Servers	11i v2	Yes	8 (maximum 4 per PCI card cage)

TCP/IP Supported Configurations

Multiple TCP/IP HyperFabric configurations are supported to match the cost, scaling and performance requirements of each installation.

In the previous “Configuration Guidelines” section the maximum limits for TCP/IP enabled HyperFabric hardware configurations were outlined. In this section the TCP/IP enabled HyperFabric configurations that HP supports will be detailed. These recommended configurations offer an optimal mix of performance, availability and practicality for a variety of operating environments.

There are many variables that can impact HyperFabric performance. If you are considering a configuration that is beyond the scope of the following HP supported configurations, contact your HP representative.

Point-to-Point Configurations


Large servers like HP's Superdome can be interconnected to run Oracle RAC 9i and enterprise resource planning applications. These applications are typically consolidated on large servers.

Point to point connections between servers support the performance benefits of HMP without investing in HyperFabric switches. This is a good solution in small configurations where the benefits of a switched HyperFabric cluster might not be required (see configuration A and configuration C in Figure 2-1).

If there are multiple point to point connections between two nodes, the traffic load will be balanced over those links. If one link fails, the load will fail-over to the remaining links (see configuration B in Figure 2-1).

Running applications using TCP/IP on a HyperFabric cluster provides major performance benefits compared to other technologies (such as ethernet). If a HyperFabric cluster is originally set up to run enterprise applications using TCP/IP and the computing environment stabilizes with a requirement for higher performance, migration to HMP is always an option.


Figure 2-1 TCP/IP Point-To-Point Configurations



Switched

This configuration offers the same benefits as the point to point configurations illustrated in figure 1, but it has the added advantage of greater connectivity (see Figure 2-2).


Figure 2-2 TCP/IP Basic Switched Configuration



High Availability Switched

This configuration has no single point of failure. The HyperFabric driver provides end to end HA. If any HyperFabric resource in the cluster fails, traffic will be transparently rerouted through other available resources. This configuration provides high performance and high availability (see Figure 2-3).

Figure 2-3 TCP/IP High Availability Switched Configuration




Hybrid

Servers and workstations can be interconnected in a single heterogeneous HyperFabric cluster.

In this configuration the servers are highly available. In addition, the workstations and the servers can be running the same application or different applications (see Figure 2-4).


Figure 2-4 TCP/IP Hybrid Configuration



Mixed HF1 / HF2 (Copper & fibre)

All currently available HyperFabric products can be interconnected in a single HyperFabric cluster. The HF1 and HF2 products are interoperable enabling user controlled migration from copper based to fibre based technologies (see Figure 2-5).

Figure 2-5 TCP/IP Mixed HF1 & HF2 Configuration



Hyper Messaging Protocol (HMP)

Hyper Messaging protocol (HMP) is Hewlett-Packard's patented, high performance cluster interconnect protocol. HMP provides reliable, high speed, low latency, low CPU overhead, datagram service to applications running on HP-UX platforms.

HMP was jointly developed with Oracle Corp. The resulting feature set was tuned to enhance the scalability of the Oracle Cache Fusion clustering technology. It is implemented using Remote DMA (RDMA) paradigms.

HMP is integral to the HP-UX HyperFabric driver. It is a functionality that can be enabled or disabled at HyperFabric initialization using `clhc_init` or SAM. The HMP functionality is used by the applications listed in the *Application Availability* section below.

HMP significantly enhances the performance of parallel and technical computing applications.

HMP firmware on HyperFabric adapter cards provides a “shortcut” that bypasses several layers in the protocol stack, boosting link performance and lowering latency. By avoiding interruptions and buffer copying in the protocol stack, communication task processing is optimized.

Although HMP is supported on some HF1 hardware (see Figure 2-6 on page 43), it is optimized to run on HF2 hardware.

Application Availability

Currently there are two families of applications that can use HMP over the HyperFabric interface:

- Oracle 9i Database, Release 1 (9.0.1) and Release 2 (9.2.0.1.0).

HMP has been certified on Oracle 9i Database Release 1 with HP-UX 11.0 and 11i.

HMP has been certified on Oracle 9i Database Release 2 with HP-UX 11.0 and 11i.

NOTE

Although HMP and TCP/IP applications are able to run simultaneously on the same HyperFabric cluster, for practical purposes, a HyperFabric cluster must run HMP applications exclusively or TCP/IP applications exclusively.

Features

- OnLine Addition and Replacement (OLAR): Not Supported

The OLAR feature, which allows the replacement or addition of HyperFabric adapter cards while the system (node) is running, is not supported when applications use HMP to communicate.

- Event Monitoring Service (EMS): Supported

Starting with the December 2000 releases B.11.00.11 and B.11.11.01, the HyperFabric EMS monitor allows the system administrator to separately monitor each HyperFabric adapter on every node in the fabric, in addition to monitoring the entire HyperFabric subsystem. The monitor can inform the user if the resource being monitored is UP or DOWN. The administrator defines the condition to trigger a notification (usually a change in interface status). Notification can be accomplished with a SNMP trap or by logging into the syslog file with a choice of severity, or by email to a user defined email address.

For more detailed information on EMS, including instructions for implementing this feature, see “Configuring the HyperFabric EMS Monitor” on page 97 in this manual, as well as the *EMS Hardware Monitors User's Guide* Part Number B6191-90028 September 2001 Edition.

- MC ServiceGuard: Supported

Within a cluster, MC/ServiceGuard groups application services (individual HP-UX processes) into packages. In the event of a single service failure (node, network, or other resource), EMS provides notification and MC/ServiceGuard transfers control of the package to another node in the cluster, allowing services to remain available with minimal interruption. MC/ServiceGuard via EMS, directly monitors cluster nodes, LAN interfaces, and services (the individual processes within an application). MC/ServiceGuard uses a heartbeat LAN to monitor the nodes in a cluster. MC/ServiceGuard cannot use the HyperFabric interconnect as a heartbeat link. Instead, a separate LAN must be used for the heartbeat.

For more detailed information on configuring MC ServiceGuard, see “Configuring HyperFabric with MC/ServiceGuard” on page 98 in this manual, as well as *Managing MC/ServiceGuard* Part Number B3936-90065 March 2002 Edition.

- High Availability (HA): Partially Supported

When applications use HMP to communicate between HP 9000 nodes in a HyperFabric cluster, MC/ServiceGuard and the EMS monitor can be configured to identify node failure and automatically fail-over to a functioning HP 9000 node. Although failure of an adapter card or a link will be detected, there will not be automatic fail-over if an adapter card or a link fails.

For more detailed information on HA when running HMP applications, consult with your HP representative.

- Dynamic Resource Utilization (DRU): Partially Supported

When a new HyperFabric resource (node, cable or switch) is added to a cluster running an HMP application, the HyperFabric subsystem will dynamically identify the added resource and start using it. The same process takes place when a resource is removed from a cluster. The distinction for HMP is that DRU is supported when a node with adapters installed in it is added or removed from a cluster running an HMP application, but DRU is not supported when an adapter is added or removed from a node that is running an HMP application. This is consistent with the fact that OLAR is not supported when an HMP application is running on HyperFabric.

- Load Balancing: Partially Supported

When an HP 9000 node that has multiple HyperFabric adapter cards is running HMP applications, the HyperFabric driver only balances the load across the available adapter cards on that node. Load Balancing is not extended to multiple links between switches or other HyperFabric resources.

- **Switch Management: Not Supported**
Switch Management is not supported. Switch management will not operate properly if it is enabled on a HyperFabric cluster.
- **Diagnostics: Supported**
Diagnostics can be run to obtain information on many of the HyperFabric components via the `clic_diag`, `clic_probe` and `clic_stat` commands, as well as the Support Tools Manager (STM).
For more detailed information on HyperFabric diagnostics, see “Running Diagnostics” on page 103 on page 149.

Configuration Parameters

This section details, in general, the maximum limits for HMP HyperFabric configurations. There are numerous variables that can impact the performance of any particular HyperFabric configuration. See the “HMP Supported Configurations” section for guidance on specific HyperFabric configurations for HMP applications.

- HyperFabric is only supported on the HP 9000 series unix servers and workstations.
- HMP is only supported on the PCI 4X adapters, A6092A and A6386A.
- Although HMP is supported on A6092A HF1 (copper) adapters, the performance advantages HMP offers will not be fully realized unless it is used with A6386A HF2 (fibre) adapters and related fibre hardware. See Table 2-6 on page 41 for details.
- **Maximum Supported Nodes and Adapter Cards:**

HyperFabric clusters running HMP applications are limited to supporting a maximum of 64 adapter cards.

In point to point configurations running HMP applications, the complexity and performance limitations of having a large number of nodes in a cluster make it necessary to include switching in the fabric. Typically, point to point configurations consist of only 2 or 3 nodes.

In switched configurations running HMP applications, HyperFabric supports a maximum of 64 interconnected adapter cards.

A maximum of 8 HyperFabric adapter cards are supported per instance of the HP-UX operating system. The actual number of adapter cards a particular node is able to accommodate also depends on slot availability and system resources. See node specific documentation for details.

A maximum of 8 configured IP addresses are supported by the HyperFabric subsystem per instance of the HP-UX operating system.

- **Maximum Number of Switches:**
Up to 4 switches (16 port copper, 16 port fibre or Mixed 8 fibre ports / 4 copper ports) can be interconnected (meshed) in a single HyperFabric cluster.
- **Trunking Between Switches (multiple connections).**
HMP is supported in configurations where switches are interconnected through multiple cables. However, with the current release of HMP software, this configuration will not eliminate a single point of failure or increase performance.

Instead, all of the traffic will be sent over a single connection with no failover capability and without the performance increase that would come from balancing the load over multiple connections.

- **Maximum Cable Lengths:**

HF1 (copper): The maximum distance between two nodes or between a node and a switch is 60 ft. (2 standard cable lengths are sold and supported: 35 ft. and 60 ft.)

HMP supports up to four HF1 switches connected in series with a maximum cable length of 60 ft. between the switches and 60 ft. between switches and nodes.

HF2 (fibre): The maximum distance is 200m (4 standard cable lengths are sold and supported: 2m, 16m, 50m and 200m).

HMP supports up to four HF2 switches connected in series with a maximum cable length of 200m between the switches and 200m between switches and nodes.

HMP supports up to 4 hybrid HF1/HF2 switches connected in series with a maximum cable length of 60 ft. between copper ports and 200m between fibre ports.

- HMP is supported on the PCI 4X adapters, A6092A and A6386A.
- HMP is supported on A400, A500, rp2400, rp2450, rp54xx (N-class), rp74xx (L-class), rp8400, and Superdome servers running 64 bit HP-UX.
- HMP is supported on J-class, B-class and C-class workstations running 64 bit HP-UX when patch number PHNE_25485 is installed.
- HMP is supported on HyperFabric from HF version B.11.00.11 forward and from HF version B.11.11.01 forward.
- HMP is not supported on V-class, A180 or A180C servers.
- HMP is not supported on 32 bit versions of HP-UX.
- Speed and Latency

Table 2-4

HF1 Speed and Latency w/ HMP Applications

Server Class	Maximum Speed	Latency
rp 7400	1.28 + 1.28 Gbps full duplex per link	< 26 microsec

Table 2-5

HF2 Speed and Latency w/ HMP Applications

Server Class	Maximum Speed	Latency
rp 7400	2 + 2 Gbps full duplex per link	< 22 microsec

Table 2-6 Supported Configurations for A6386A HF2 Adapter On PCI (4X)

Supported HP 9000 Systems	HP-UX Version	OLAR Support?	Maximum Adapters per System
rp24xx (A400 and A500)	11.0, 11i v1, 11iv2	No	2
rp34xx Series	11i v1 and 11i v2	No	2
rp44xx Series	11i v1 and 11i v2	Yes	4
rp54xx Series (L Class Servers)	11.0, 11i v1 and 11i v2	Yes (11iv1 and later)	8 (maximum 4 per PCI card cage)
rp74x0 (N-Class Series)	11.0, 11i v1 and 11i v2	Yes	8
rp84x0	11i v1 and 11i v2	Yes	8 (maximum 4 per PCI card cage)
rx1600 Servers	11i v2	Yes	8
rx2600 Servers	11i v2	No	1
rx4640 Servers	11i v2	Yes	4
rx56xx Series	11i v2	No	4
rx7620 Servers	11i v2	No	8 (maximum 4 per PCI card cage)
rx8620 Servers	11i v2	Yes	8 (maximum 4 per PCI card cage)
zx6000 Workstations	11i v2	No	1
B1000, B2000, B2600, C3000, C3600, C3700, J5000, J5600, J6000, J6700 and J7000 workstations	11.0, 11i v1	No	2
Superdome servers	11i v1 and 11i v2	Yes	8 (maximum 4 per PCI card cage)
SD64A Servers	11i v2	Yes	8 (maximum 4 per PCI card cage)

HMP Supported Configurations

Multiple HMP HyperFabric configurations are supported to match the performance, cost and scaling requirements of each installation.

In the previous “Configuration Guidelines” section, the maximum limits for HMP enabled HyperFabric hardware configurations were outlined. In this section, the HMP enabled HyperFabric configurations that HP supports will be detailed. These recommended configurations offer an optimal mix of performance, availability and practicality for a variety of operating environments.

There are many variables that can impact HyperFabric performance. If you are considering a configuration that is beyond the scope of the following HP supported configurations, contact your HP representative.

Point to Point


Large servers like HP's Superdome can be interconnected to run Oracle RAC 9i and enterprise resource planning applications. These applications are typically consolidated on large servers.

Point to point connections between servers support the performance benefits of HMP without investing in HyperFabric switches. This is a good solution in small configurations where the benefits of a switched HyperFabric cluster might not be required (see configurations A and B in Figure 2-6).


If an HMP application is running over the HyperFabric and another node is added to either of the point to point configurations illustrated in Figure 2-6, it will be necessary to also add a HyperFabric switch to the cluster.

Figure 2-6 HMP Point-To-Point Configurations

(Configuration A)
SINGLE CONNECTION BETWEEN TWO NODES



(Configuration B)
MULTIPLE CONNECTIONS BETWEEN TWO NODES



Enterprise (Database)

The HMP enterprise configuration illustrated in Figure 2-7 is very popular for running Oracle RAC 9i.

Superdomes or other large servers make up the Database Tier.

Database Tier nodes communicate with each other using HMP.

Application Tier nodes communicate with each other and to the Database Tier using TCP/IP.

The HMP enterprise configuration is a scalable solution. If higher performance is required, or if eliminating single points of failure is necessary, scaling up to the HMP enterprise configuration with multiple connections between nodes is easily accomplished (see Figure 2-8).

Although each of the servers in the Application Tier could also have multiple adapter cards and multiple connections to switches, link and adapter card failover capabilities are not currently available for HMP.

Figure 2-7 HMP Enterprise (Database) Configuration, Single Connection Between Nodes





Figure 2-8 HMP Enterprise (Database) Configuration, Multiple Connections Between Nodes



Technical Computing (Work Stations)

This configuration is typically used to run technical computing applications with HP-MPI. A large number of small nodes are interconnected to achieve high throughput (see Figure 2-9). High availability is not usually a requirement in technical computing environments.

HMP provides the high performance, low latency path necessary for these technical computing applications. As many as 56 nodes can be interconnected using HP's 16 port switches. Not more than four 16 port switches can be linked in a single cluster (see Figure 2-10).

HP's "J", "B" and "C" class workstations provide excellent performance and return on investment in technical computing configurations.

Figure 2-9 **Technical Computing Configuration**





Figure 2-10 **Large Technical Computing Configuration**



3 Installing HyperFabric

This chapter contains the following sections that describe installing HyperFabric:

- “Checking HyperFabric Installation Prerequisites” on page 53
- “Installing HyperFabric Adapters” on page 54
- “Installing the Software” on page 60

- “Installing HyperFabric Switches” on page 66

Checking HyperFabric Installation Prerequisites

Before installing HyperFabric, check to make sure the following hardware and software prerequisites have been met:

- ✓ Check the *HP HyperFabric Release Note* for any known problems, required patches, or other information needed for installation.
- ✓ Confirm the `/usr/bin`, `/usr/sbin`, and `/sbin` directories are in your `PATH` by logging in as `root` and using the `echo $PATH` command.
- ✓ Confirm the HP-UX operating system is the correct version. Use the `uname -a` command to determine the HP-UX version.

See the *HP HyperFabric Release Note* for information about the required operating system versions.

- ✓ If you are installing an HF2 switch, confirm that you have four screws with over-sized heads.
- ✓ Confirm there are cables of the proper length and type (copper or fibre) to make each of the connections in the fabric (adapter to adapter, adapter to switch, or switch to switch).

IMPORTANT: Copper adapters and switch ports can only be connected to other copper adapters and switch ports and fibre adapters and switch ports can only be connected to other fibre adapters and switch ports.

- ✓ Confirm there is at least one loopback plug for testing the adapters and switches (a copper loopback plug is shipped with each HF1 adapter and a fibre loopback plug [HP part number A6384-67004] is shipped with each HF2 switch).
- ✓ Confirm the necessary tools are available to install the HyperFabric switch mounting hardware. Also check the HP 9000 system documentation to determine if any additional tools may be required for component installation.
- ✓ Confirm software media is correct.
- ✓ Create a map of the fabric (optional).
- ✓ Confirm HP-UX super-user privileges are available, they will be necessary to complete the HyperFabric installation.

The first HyperFabric installation step is installing HyperFabric adapter cards in the nodes. Proceed to the next section “Installing HyperFabric Adapters”.

Installing HyperFabric Adapters

This section contains information about installing HyperFabric adapters in HP 9000 systems. Online Addition and Replacement (OLAR) information is provided in the “Online Addition and Replacement—HP-UX 11i Only” section on page 62.

CAUTION

HyperFabric adapters contain electronic components that can easily be damaged by small amounts of electricity. To avoid damage, follow these guidelines:

- Store adapters in their antistatic plastic bags until installation.
- Work in a static-free area, if possible.
- Handle adapters by the edges only. Do not touch electronic components or electrical traces.
- Use the disposable grounding wrist strap provided with each adapter. Follow the instructions included with the grounding strap.
- Use a suitable ground—any exposed metal surface on the computer chassis.

IMPORTANT

Although the A6092A (copper) adapter is supported on HP 9000 Superdome systems, we recommend that only fibre adapters be installed in Superdome systems. The reason is that the A4892A copper HF1 cable is not flexible enough to use in the cable management system in the Superdome chassis—to use the copper cable in a Superdome, it would likely be necessary to remove some parts of the Superdome cabinet.

WARNING

User Note: HyperFabric adapter installation in V-Class systems must be done by a Hewlett-Packard Customer Engineer qualified in installing and servicing the HP V-Class system and trained to recognize the hazards involved. The I/O board is installed in an area of the V-Class where hazardous energy levels might be produced. Any attempt by non-HP personnel to install a HyperFabric adapter in a V-Class system might result in a void of warranty.

Customer Engineer Note: Refer to the V-Class system's documentation to identify various areas of the V-Class card cage. The PCI HyperFabric adapters are installed in one of the V-Class's Exemplar I/O boards. Only one HyperFabric adapter per V-Class SAGA/EPIC is supported.

For specific instructions see system specific documentation on “installing networking adapters” for each type of HP 9000 system that HyperFabric adapters will be installed into.

When the HyperFabric adapters have been installed, go to “Installing the Software” on page 60.

Online Addition and Replacement—HP-UX 11i Only

Online Addition and Replacement (OLAR) allows PCI I/O cards, adapters or controllers to be replaced or added to HP 9000 systems, without the need for completely shutting down and rebooting the system, or adversely affecting other system components. This feature is only available on HP 9000 systems that are designed to support OLAR. The system hardware uses the per-slot power control combined with OS support to enable this feature.

Not all add-in cards have this capability, but over time many cards will be gaining this capability.

The latest *HyperFabric Release Notes* contains information about which HP 9000 systems and HyperFabric adapters OLAR is supported for.

IMPORTANT

At this time V-Class and Superdome systems are not intended for access by users. HP recommends that these systems only be opened by a qualified HP engineer. Failure to observe this requirement can invalidate any support agreement or warranty to which the owner might otherwise be entitled.

There are two methods to add or replace OLAR-compatible cards:

- Using the SAM utility.
- Issuing command-line commands, through `rad`, that refer to the HyperFabric OLAR script (`/usr/sbin/olard.d/clicd`).

HP recommends that SAM be used for OLAR procedures, instead of the `rad` command. This is primarily because SAM prevents the user from doing things that might have adverse effects. This is not true when the `rad` command is used.

For detailed information about using either of these two procedures, see *Configuring HP-UX For Peripherals*. You can order that document from Hewlett-Packard, or you can view, download, and print it from this URL: <http://www.docs.hp.com>.

Table 3-1 below explains some important OLAR-related terms.

Table 3-1 **Important OLAR Terms**

Term	Meaning
OLAR	All aspects of the OLAR feature including Online Addition (OLA) and Online Replacement (OLR).
Power Domain	A grouping of 1 or more interface card slots that are powered on or off as a unit. (Note: Multi-slot power domains are not currently supported.)
target card / target card slot	The interface card which will be added or replaced using OLAR, and the card slot in which it resides.
affected card / affected card slot	Interface cards and the card slots they reside in, which are in the same power domain as the target slot.

IMPORTANT

In many cases, other interface cards and slots within the system are dependent on the target card. For example, if the target card is a multiple-port card, suspending or deleting drivers for the target card slot also suspends individual drivers for the multiple hardware paths on that card.

During a card replacement operation, SAM performs a **Critical Resource Analysis (CRA)**, which checks all ports on the target card for critical resources that would be temporarily unavailable while the card is shut down.

Planning and Preparation

As mentioned previously, for the most part, SAM prevents the user from performing OLAR procedures that would adversely affect other areas of the HP 9000 system. See *Configuring HP-UX For Peripherals* for detailed information.

Critical Resources

The effects of shutting down a card's functions must be considered. Replacing a card that is still operating can have extensive consequences. Power to a slot must be turned off when a card is removed and a new card is inserted.

This is particularly important if there is no online failover or backup card to pick up those functions. For example:

- Which mass storage devices will be temporarily disconnected when a card is shut down?
- Will a critical networking connection be lost?

A critical resource is one that would cause a system crash or prevent an operation from successfully completing if the resource were temporarily suspended or disconnected. For example, if the SCSI controller is connected to the unmirrored root disk or swap space, the system will crash when the SCSI controller is shut down.

During an OLAR procedure, it is essential to check the targeted card for critical resources, as well as the effects of existing disk mirrors and other situations where a card's functions can be taken over by another card that will not be affected.

Fortunately, as mentioned earlier, SAM performs a thorough CRA automatically, and presents options based on its findings. If it is determined that critical resources will be affected by the OLAR procedure, the card could be replaced when the system is offline. If action must be taken immediately, an online addition of a backup card and deletion of the target card could be attempted using rad.

Card Compatibility

This section explains card compatibility considerations for doing OLAR.

Online Addition (OLA) Multiple cards can be added at the same time. When adding a card online, the first issue to resolve is whether the new card is compatible with the system. Each OLAR-capable PCI slot provides a set amount of power. The replacement card cannot require more power than there is available.

The card must also operate at the slot's bus frequency. A PCI card must run at any frequency lower than its maximum capability, but a card that could operate at only 33 MHz would not work on a bus running at 66 MHz. `rad` provides information about the bus frequency and power available at a slot, as well as other slot-related data.

If an HP 9000 system has one or more slots that support OLAR and OLA will be used to install a HyperFabric adapter in one of those slots—install the adapter in the HP 9000 system according to the procedure described in the “Managing PCI Cards with OLAR” chapter of the *“Configuring HP-UX Peripherals”* manual.

After adding a new HyperFabric adapter, SAM tries to locate the HyperFabric software. If SAM cannot locate the HyperFabric software, the new adapter cannot be used until the software is installed (remember that software installation requires a system reboot). If SAM locates the HyperFabric software, SAM determines whether the new adapter is functional. If it is not functional, SAM displays an error message.

If the new adapter is functional, SAM displays a message telling the user to configure the adapter and start HyperFabric. If only one adapter is being added, issue the `clhc_init -c` command or use SAM to configure the adapter, and then issue the `clhc_start` command or use SAM to start HyperFabric. If multiple adapters are being added, add all of the adapters first, and then run `clhc_init -c` and `clhc_start` or use SAM. (Remember, using SAM to configure an adapter or start HyperFabric is available on HP-UX 11.0 and 11i only.) See “Doing the Configuration” on page 91 and “Starting HyperFabric” on page 85 for more information about configuring and starting HyperFabric.

CAUTION

Do not change any configuration information for an existing HyperFabric adapter or switch while you are using `clhc_init -c` to configure a new adapter.

When you have completed the adapter installation, go to “Installing the Software” on page 60.

Online Replacement (OLR) When replacing an interface card online, the replacement card must be identical to the card being replaced (or at least be able to operate using the same driver as the replaced card). This is referred to as **like-for-like** replacement and should be adhered to, because using a similar but not identical card can cause unpredictable results. For example, a newer version of the target card that is identical to the older card in terms of hardware might contain an updated firmware version that could potentially conflict with the current driver. An A6092A adapter must be replaced with another A6092A adapter. An A6386A adapter must be replaced with another A6386A adapter, etc. Also, the old adapter and new adapter must have the same revision levels.

When a replacement card is added to an HP 9000 system, the appropriate driver for that card must be configured in the kernel before beginning the replacement operation. SAM ensures the correct driver is present. (In most cases, the replacement card will be the same type as a card already in the system, and this requirement will be automatically met.) Keep the following things in mind:

- If the necessary driver is not present and the driver is a dynamically loadable kernel module (DLKM), it can be loaded manually. See the “Dynamically Loadable Kernel Modules” section in *“Configuring HP-UX For Peripherals”* for more information.

- If the driver is static and not configured in the kernel, then the card cannot be added online. The card could be physically inserted online, but no driver would claim it.

If there is any question about the driver's presence, or if it is uncertain that the replacement card is identical to the existing card, `ioscan` can be used together with `rad` to investigate.

If more than one operational HyperFabric adapter is present when SAM requests the suspend operation for all ports on the target adapter, HyperFabric will redirect the target adapter's traffic to a local backup adapter using local failover. Client applications using the replaced adapter will not be interrupted in any way.

If the adapter being replacing is active and it is the only operational HyperFabric adapter on the HP 9000 system, SAM displays the following warning message:

```
WARNING: You have 1 operational HyperFabric card.  If you go ahead with this
operation you will lose network access via HyperFabric until the on-line
replaced HyperFabric card becomes operational.
```

You are asked if you want to continue. If you reply Yes, client applications are suspended. Replace the adapter according to the procedure described in the "Managing PCI Cards with OLAR" chapter of the *Configuring HP-UX Peripherals* manual.

When an adapter has been replaced, client application activity resumes unless the TCP timers or the application timers have popped.

CAUTION

Do not use the `clic_start` command or the `clic_shutdown` command, while an installed adapter is suspended. Do not use SAM to start or stop HyperFabric while an installed adapter is suspended. The operation will fail and an error message will be displayed.

After a HyperFabric adapter has been replaced, SAM checks the replacement adapter to make sure it is permitted according to the like-for-like rules. If the adapter is permitted, SAM automatically activates it. If it is not permitted, SAM displays an error message.


Installing the Software

This section describes the HyperFabric file structure and the steps necessary to load the software. The software must be installed on each instance of the HP-UX operating system in the fabric.

File Structure

The HyperFabric file structure is shown in Figure 3-1 below. Note that the structure is shown for informational purposes only. The user cannot modify any of the files or move them to a different directory.

Figure 3-1 HyperFabric File Structure



The commands and files used to administer HyperFabric typically have a prefix of `cltc_`. CLIC stands for CLuster InterConnect, and it is used to differentiate those HyperFabric commands/files from other commands/files. For example, the HyperFabric command `cltc_init` is different from the HP-UX `init` command.

Each of the files shown in Figure 3-1 above is briefly described below:

- `/etc/opt/resmon/dictionary/cltc_01`

The HyperFabric dictionary file for the Event Monitoring Service (EMS).

- `/etc/rc.config.d/cltc_global_conf`

The global configuration file, which contains the IP addresses for each adapter and each HyperFabric switch (if any) in the fabric.

- `/sbin/init.d/clic`

The system boot startup script for the HyperFabric management process.

- `/var/adm/clic_ip_drv.trc`

One of the software's trace files. This file is created when the `clic_diag -D TCP_IP` command is run.

- `/var/adm/clic_ip_drv.trc0`

One of the HyperFabric software's trace files. This is the primary file that is created when the `clic_diag -C TCP_IP` command is run.

- `/var/adm/clic_ip_drv.trc1`

One of the HyperFabric software's trace files. This file is created when the `clic_diag -C TCP_IP` command is run, and the primary trace file (`clic_ip_drv.trc0`) becomes full.

- `/var/adm/clic_log`

The global log file that is updated by the HyperFabric management process.

- `/var/adm/clic_log.old`

The backup copy of the log file that is created when the log file grows larger than 100 Kbytes.

- `/var/adm/OLDclirc_log`
The log file from the previous time the `clirc_start` command was executed.
- `/usr/conf/lib/libclirc_dlpi_drv.a`
The kernel library that contains the HyperFabric software.
- `/usr/conf/lib/libha_drv.a`
The kernel library that contains the High Availability (HA) software.
- `/usr/conf/master.d/clirc`
This file is described along with the other master files in the `master` man page (type `man master` at the HP-UX prompt).
- `/opt/clirc/lib/libclirc_mgmt.a`
The HyperFabric management API library.
- `/opt/clirc/bin`
The directory containing the HyperFabric management commands: `clirc_diag`, `clirc_init`, `clirc_probe`, `clirc_shutdown`, `clirc_start`, `clirc_stat`, and `clirc_dump`. (Note that `clirc_dump` is for HP internal use only.) Also, although `clirc_ping` was replaced by `clirc_probe` beginning with HyperFabric versions B.11.00.11 and B.11.11.01, it is still supported for HP-UX 10.20 HyperFabric version B.10.20.11. This directory also contains the HyperFabric management process (`clirc_mgmt`) and the HyperFabric EMS monitor process (`clirc_mond`).
- `/opt/clirc/firmware/clirc_fw`
The 1X HSC HyperFabric 8-bit CRC firmware. Note that this file must not be modified for any reason.
- `/opt/clirc/firmware/clirc_fw_1x32c`
The 1X HSC HyperFabric 32-bit CRC firmware. Note that this file must not be modified for any reason.

- `/opt/clic/firmware/clic_fw_4x8c`

The 4X PCI HyperFabric 8-bit CRC firmware. Note that this file must not be modified for any reason.

- `/opt/clic/firmware/clic_fw_4x32c`

The 4X HyperFabric PCI 32-bit CRC firmware. Note that this file must not be modified for any reason.

- `/opt/clic/firmware/clic_fw_hf28c`

The HyperFabric2 8-bit firmware. Note that this file must not be modified for any reason.

- `/opt/clic/firmware/clic_fw_hf232c`

The HyperFabric2 32-bit firmware. Note that this file must not be modified for any reason.

- `/opt/clic/firmware/clic_fw_db`

A binary file where adapter-specific configuration information is stored. The management process creates this file using default values.

- `/opt/clic/share/man/man1m.Z`

The man pages for the HyperFabric commands.

Loading the Software

Listed below are the steps you must follow to load the HyperFabric software, using the HP-UX `swinstall` program.

Step 1. Log in as `root`.

Step 2. Insert the software media into the appropriate drive. If the software is being loaded from a CD-ROM, go to step 3. Otherwise, go to step 4.

Step 3. Mount the CD-ROM drive by using this command:

```
mount device_name
```

where *device_name* is the name assigned to the CD-ROM drive.

Step 4. Run the `swinstall` program using this command:

```
/usr/sbin/swinstall
```

This opens the “Software Selection” window.

Step 5. Change the Source Host Name, if necessary, and then enter the mount point of the drive in the Source Depot Path field. Select the OK button to return to the “Software Selection” window.

The “Software Selection” window now contains a list of available software to install.

Step 6. Highlight the HyperFabric software:

- HP-UX 10.20 and 11.0: B6257AA
- HP-UX 11i: HyperFabric-00

Step 7. Choose Mark for Install from the “Actions” menu; this chooses the highlighted software.

Step 8. From the “Actions” menu, pull down the “Install...” menu, and then choose Install. This begins product installation and opens the “Install Analysis” window.

Step 9. Select the OK button in the “Install Analysis” window when the Status field displays a “Ready” message.

Step 10. Select the YES button in the “Confirmation” window to start software installation.

`swinstall` loads the fileset, runs the control script for the filesets, and builds the kernel. When the processing is finished, the “Status” field displays a “Ready” message. Select “Done” and then the “Note” window opens.

Step 11. Select the OK button in the “Note” window to reboot. The user interface disappears and the system reboots.

Step 12. When the system comes back up, log in as `root` and view the `/var/adm/sw/swagent.log` and `/var/adm/sw/swinstall.log` files to view any error or warning messages that might have occurred during the installation.

Step 13. While still logged in as `root`, view the `/etc/services` file to ensure that these two HyperFabric-related lines are present:

- `hp-clic 3384/tcp #clic management daemon`

- `hp-clic 3384/udp #clic switch management`

Note that these lines are used by the HyperFabric software—and are not comments—so do not remove them from the file.

Step 14. Verify that all installed HyperFabric adapters have a software state of “CLAIMED,” by running the `ioscan -nf -C clic` command.

Note: A check is also done to make sure all of the HyperFabric adapters have been claimed when `clic_init` is activated or when SAM is used to configure HyperFabric.

Step 15. If one or more HyperFabric switches are included in the configuration, go to the next section of this chapter, “Installing HyperFabric Switches”, otherwise, go to Chapter 4, “Configuring HyperFabric,” on page 83.

Installing HyperFabric Switches

This section contains the information you need to install HyperFabric switches. As stated earlier, in this manual the term **HyperFabric2 (HF2) switch** refers to the functional switch (the A6384A switch chassis with one of the switch modules installed).

Before Installation

Before you install the HyperFabric switch, you should be aware of these things:

- ❑ The A4891A HF1 switch is supported beginning with the following HyperFabric software versions:
 - HP-UX 10.20: version B.10.20.02
 - HP-UX 11.0: version B.11.00.02
 - HP-UX 11i: version B.11.11.00

The A6384A HF2 switch is supported beginning with the following HyperFabric software versions:

- HP-UX 11.0: version B.11.00.11
- HP-UX 11i: version B.11.11.01

HyperFabric switches are not supported by software versions earlier than those mentioned above, respectively.

To determine the version of HyperFabric you have, issue this command:

```
swlist | grep -i hyperfabric
```

- ❑ The HF1 switch must be rack mounted in a standard 19-inch rack, using the rails shipped with the switch.

For the HF2 switch, we recommend that you use the rails shipped with the switch when you mount it in a standard 19-inch rack, even though the switch can be mounted in the rack by itself (without the rails).

CAUTION: To prevent overheating, you must leave one rack unit (1 EIA) of empty space above the HyperFabric switch.

- ❑ After the HyperFabric switch is mounted in the rack, you attach the various cables to the switch.

To avoid damage to any of the cables, follow these guidelines:

- If your cables have dust caps over the connectors, keep them in place until you are ready to connect them. This prevents dirt and oils from soiling any important surfaces.
- Be careful not to stretch, puncture, or crush the cable.

To install a HF1 switch see the next section, “Steps for Installing the HF1 Switch”.


To install an HF2 switch, see “Installing the HF2 Switch” on page 76.

Steps for Installing the HF1 Switch

This section contains information for installing a HF1 switch. As mentioned earlier, the HF1 switch must be mounted using the rail kit shipped with the switch.

Figure 3-2 below shows the locations of the ports, LEDs, and power cord inlet on the back of the HF1 switch.


Figure 3-2 **Back of HF1 Switch**




When you install the HF1 switch, you will be putting the front of the switch at the front of the rack. The steps for installing the HF1 switch are as follows:

Step 1. Prepare the rack for rail and switch installation.

- Step 2.** Install and secure the rails in the rack, using two screws per rail. The figure below shows the rack with the rails installed.




- Step 3.** From the front of the rack, install a bracket on the outside of each rail, using two screws per bracket. Be sure to use the upper screw holes on each bracket. Put the screws in the second and third square holes—counting away from yourself—in each rail. Do not tighten the screws. These brackets—referred to as “bracket 1” and “bracket 2” in these steps—will secure the front of the switch. The following figure shows the rack with these two brackets installed.




Step 4. From the back of the rack, slide the switch—with the front of the switch facing the front of the rack—into the rack, on the rails. Move it until it is touching brackets 1 and 2. Note that you might not have enough clearance between the switch and the rail screws, so

that you cannot easily slide the switch. If so, try lifting the switch over the rail screws. If you cannot do this, remove the rail screws, slide the switch into position, and put the rail screws back in. The figure below shows the rack with the switch in this position.




- Step 5.** From the back of the rack, install a bracket on the outside of each rail, using two screws per bracket. Be sure to use the upper screw holes on each bracket. Put the screws in the seventh and eighth square holes—counting away from yourself—in each rail. Do not tighten the screws. These brackets—referred to as “bracket 3” and “bracket 4” in these steps—will secure the back of the switch. The following figure shows the rack with these two brackets installed.




Step 6. Tighten all four screws in brackets 3 and 4.

- Step 7.** From the front of the rack, push the switch so that it barely touches brackets 3 and 4. The figure below shows how to move the switch to this position.



Step 8. Once the switch is snug against brackets 3 and 4, push brackets 1 and 2 in towards the switch, so that they are snug against the switch. The figure below shows brackets 1 and 2 in this position.



Step 9. Tighten the four screws in brackets 1 and 2.

Step 10. For each port that will be connected to an HF1 adapter in an HP 9000 system, attach the cable from the corresponding adapter. Remember, your connections must be copper-to-copper and fibre-to-fibre (including cables).

Step 11. Connect the switch to the Ethernet network.

- Step 12.** Plug the switch's power cord into the rack's power distribution unit (PDU), if it has one. Alternatively, you can plug a power cord that is compatible with your country's requirements into a power strip or outlet that you want to use for the switch. (In this case, you are responsible for obtaining a compatible power cord.)
- Step 13.** Power on the HF1 switch by plugging the power cord into the AC inlet on the back of the switch. (There is no power switch.) Once the power is on, the "Power" LED shows solid green.
- Step 14.** Check that, for each HF1 switch port that is connected to an HF1 adapter, the LED on the port shows as solid green (see Figure 3-2 on page 68). This means the connection is operational.
- Step 15.** Check that the "Ethernet" LED on the switch's Ethernet port is showing solid green (connected) or flashing green (Ethernet traffic is flowing to the switch). See Figure 3-2 on page 68 for the location of the LED.
- For more detailed information about the switch's LEDs, see "HF1 Switch LEDs" on page 114.
- Step 16.** If you want to install another HF1 switch, go back to step 1.
Otherwise, go to step 17.
- Step 17.** If you want to install one or more HF2 switches, go to the next section, "Installing the HF2 Switch".
Otherwise, go to Chapter 4, "Configuring HyperFabric," on page 83.

Installing the HF2 Switch

This section contains information for installing an HF2 switch.

The front of the HF2 switch has a flange—or “wing”—on each side, with two holes for attaching the switch to the rack. Note that the two figures below do not show the flanges.

Figure 3-3 below shows the front of the HF2 switch with an A6388A HF2 8-port fibre switch module installed in the switch’s expansion slot.

Figure 3-3 Front of HF2 Switch (A6388A Switch Module Installed)





Figure 3-4 below shows the front of the HF2 switch with an A6389A HF2 4-port copper switch module installed in the switch’s expansion slot.

Figure 3-4 Front of HF2 Switch (A6389A Switch Module Installed)



You can install the HF2 switch in one of these two ways:

- Using the rail kit that is shipped with the switch (see the next section, “With the Rail Kit”). Note that HP strongly recommends installing the HF2 switch this way.
- Attaching the switch directly to the rack (see “Without the Rail Kit” on page 81).


With the Rail Kit

HP recommends that you install the HF2 switch using the rail kit that is shipped with the switch. The rail kit includes two adjustable rails, screws, nuts, and washers.

To install the HF2 switch, you need eight screws and four nuts. Use the square cage nuts if you are installing the HF2 switch in a square-hole rack. Use the u-type clip nuts if you are installing the HF2 switch in a round-hole rack.

Figure 3-5 shows various parts that are shipped with the rail kit.

Figure 3-5 **Parts of the Rail Kit**



The rail kit does not include hold-down brackets for the rear of the switch. HP does not recommend transporting the rack with the switch installed. HP recommends that two people install the HF2 switch.


Installing the HF2 Switch With the Rail kit

When you install the HF2 switch, you must put the front of the switch—the end with the flanges (“wings”)—at the back of the rack. To install the HF2 switch using the rail kit, complete the following steps:

- Step 1.** Prepare the rack for rail and switch installation.
- Step 2.** Remove all the screws if you receive the rail kit with all ten screws secured in to the rails.

One end of each rail has six screw-holes (End-A), the other end has two screw holes (End-B). Figure 3-6 shows both the ends of the rail.

Figure 3-6 The Ends of the Rail Kit



- Step 3.** Orient the rails so that End-A faces the back of the rack and aligns with the front end of the switch with flanges.
- Step 4.** Loosen the wing nuts on each rail and adjust the length of each rail to fit the length of the rack. End A mounts inside the rack column, and End-B mounts outside the rack column.
- Step 5.** Tighten the wing nuts on each rail after you have adjusted the length properly.
- Step 6.** Install and secure the rails in the rack, using two screws per rail. Do not secure End-A. To secure End-B, complete the following steps:
1. If you have square-hole racks, affix two cage nuts inside each rack column. Align these cage nuts with the two holes in End-B of each rail. Secure the assembly with two screws in End-B of each rail.
 2. If you have round-hole racks, affix two clip nuts to each rack column. Align these clip nuts with the two holes in End-B of each rail. Secure the assembly with two screws in End-B of each rail.
- Step 7.** To install the switch, complete the following steps:
1. Orient the front end of the switch (the end with the flanges) toward the back of the rack.
 2. Place the switch on the rails and slide it in to the rack until the flanges are snug against the outside of the rack columns.

NOTE

HP recommends employing two people to support the weight of the switch because End-A of the rail is not yet secured.

Step 8. Secure the switch and End-A of each rail by aligning the two holes in each flange with the two holes in each rack column, and two of the holes in each rail. Secure the entire assembly with two screws in each flange.

Step 9. Attach the cable from the corresponding adapter for each port that is connected to a HyperFabric adapter in an HP 9000 system.

NOTE

Your connections must be copper-to-copper and fibre-to-fibre (including cables).

Step 10. Connect the switch to the Ethernet network.

Step 11. Plug the switch's power cord in to the rack's Power Distribution Unit (PDU), if it has one.

NOTE

Ensure that you plug a power card that is compatible with your country's specifications in to a power strip or outlet that you want to use for the switch. In such a scenario, you are responsible for obtaining a compatible power cord.

Step 12. Power on the HF2 switch by plugging the power cord into the AC inlet on the back of the switch. (There is no power switch.)

Step 13. Once the power is on, check these LEDs on the integrated Ethernet management LAN adapter card in the top slot of the switch:

- ✓ The "Operating/Fault" LED shows solid green.
- ✓ The "Power A" and "Power B" LEDs show solid green.
- ✓ The "Ethernet Port Main" and "Ethernet Port Aux" LEDs show solid green (connected) or flashing green. This indicates that ethernet traffic is flowing to the switch. For information about locating the LEDs, see Figure 3-3 on page 76 or Figure 3-4 on page 77.

Step 14. On the integrated 8-port fibre card in the middle slot of the switch, check whether the LED for each switch port that is connected to an HF2 adapter shows solid green. If the LED shows solid green, it means the connection is operational.

Step 15. On the switch module in the expansion slot in the bottom slot of the switch, check whether the LED for each switch port that is connected to an HF2 adapter shows solid green. If the LED shows solid green, it means the connection is operational.

For more information about the switch's LEDs, see "HF2 Switch LEDs" on page 118.

Repeat steps 1 to 16 to install another HF2 switch using the rail kit. For information about installing an HF2 switch without using a rail kit, see "Without the Rail Kit" on page 81.

Without the Rail Kit

As mentioned earlier, HP strongly recommends installing the HF2 switch using the rail kit (described in the previous section, “With the Rail Kit” on page 78).

When you install the HF2 switch, you will be putting the front of the switch—the end with the flanges (“wings”)—at the back of the rack. The steps for installing the HF2 switch without using the rail kit are as follows:

- Step 1.** Prepare the rack for switch installation.
- Step 2.** Insert the HF2 switch into the rack, with the front of the switch snug against the back of the rack.
- Step 3.** Align the two holes in each flange on the switch's front with the holes in the rack frame.
- Step 4.** Fasten each flange of the switch to the rack by putting a screw in each of the four holes in the flanges. Be sure to use screws with over-sized heads.
- Step 5.** Tighten all of the screws so that the HF2 switch is firmly mounted in the rack.
- Step 6.** For each port that will be connected to an HyperFabric adapter in an HP 9000 system, attach the cable from the corresponding adapter. Remember, your connections must be copper-to-copper and fibre-to-fibre, including cables.
- Step 7.** Connect the switch to the Ethernet network.
- Step 8.** Plug the switch's power cord into the rack's power distribution unit (PDU), if it has one. Alternatively, you can plug a power cord that is compatible with your country's requirements into a power strip or outlet that you want to use for the switch. (In this case, you are responsible for obtaining a compatible power cord.)
- Step 9.** Power on the HF2 switch by plugging the power cord into the AC inlet on the back of the switch. (There is no power switch.)
- Step 10.** Once the power is on, check these LEDs on the integrated Ethernet management LAN adapter card (in the top slot of the switch):
 - ✓ The “Operating/Fault” LED shows solid green.
 - ✓ The “Power A” and “Power B” LEDs show solid green.
 - ✓ The “Ethernet Port Main” and “Ethernet Port Aux” LEDs are showing solid green (connected) or flashing green (Ethernet traffic is flowing to the switch). See Figure 3-3 or Figure 3-4 below for the locations of the LEDs.
- Step 11.** On the integrated 8-port fibre card (in the middle slot of the switch), check that for each switch port that is connected to an HF2 adapter, the LED on the port shows as solid green (see Figure 3-3 on page 76 or Figure 3-4 on page 77). This means the connection is operational.
- Step 12.** On the switch module in the expansion slot (the bottom slot of the switch), check that for each switch port that is connected to a HyperFabric adapter, the LED on the port shows as solid green (see Figure 3-3 on page 76 or Figure 3-4 on page 77). This means the connection is operational.

For more detailed information about the switch's LEDs, see “HF2 Switch LEDs” on page 118.
- Step 13.** If you want to install another HF2 switch without using the rail kit, go to step 1.

If you want to install another HF2 switch using the rail kit, go to “With the Rail Kit” on page 78.

Otherwise, go to Chapter 4, “Configuring HyperFabric,” on page 83.

4 Configuring HyperFabric

This chapter contains the following sections that describe configuring HyperFabric:

- “Configuration Overview” on page 85
- “Information You Need” on page 86
- “Doing the Configuration” on page 91

- “Deconfiguring a HyperFabric Adapter with SAM—HP-UX 11.0 and 11i Only” on page 96
- “Configuring the HyperFabric EMS Monitor” on page 97
- “Configuring HyperFabric with MC/ServiceGuard” on page 98

Configuration Overview

You do not need to configure the HyperFabric switch because the HyperFabric management process performs automatic routing and configuring for the switch. So, configuring HyperFabric consists only of creating the HyperFabric `/etc/rc.config.d/clic_global_conf` global configuration file on each node in the fabric. The configuration file contains the following information:

- The IP addresses and subnet mask of the HyperFabric adapters installed in the node.
- For each HyperFabric switch in the fabric—the switch's IP address, and the MAC address of the switch's Ethernet port. Note that this applies only if you enable switch management. Also note that you cannot enable switch management through SAM—you must use the `clic_init` command.
- The IP multicast address that all the switches and nodes in the fabric will register to (if you are going to enable switch management).
- The IP address of the local node's Ethernet LAN interface. This LAN interface must be on the same subnet as the Ethernet port(s) of the HyperFabric switch(es) (if you are going to enable switch management). (Note that a node might have multiple LAN interfaces.)
- Whether the node can interoperate with nodes that are using any HP-UX 10.20 version of HyperFabric, any HP-UX 11.0 HyperFabric versions earlier than B.11.00.11 or any HP-UX 11i HyperFabric versions earlier than B.11.11.01.

NOTE

We recommend that you do not enable switch management.

You can create the global configuration file by either (1) running the `clic_init` command or (2) using SAM (on HP-UX 11.0 and 11i only) to configure each HyperFabric adapter.

`clic_init` and SAM also put the necessary entries into the following three files:

- The system `/etc/rc.config.d/netconf` file.
IMPORTANT: In this file, `clic_init` and SAM add some HyperFabric-related lines that end with the characters `#clic`. These lines are used by the HyperFabric software—and are *not* comments—so do not remove them from the file.
- The system `/etc/rc.config.d/clic_global_conf` file.
- The `/etc/rarpd.conf` (Reverse Address Resolution Protocol [RARP]) support file. This file is used in the management of the HyperFabric switches (if you are going to enable switch management).

The `clic_init` command is described in “Using the `clic_init` Command” on page 92. Using SAM to configure an adapter is described in “Using SAM—HP-UX 11.0 and HP-UX 11i” on page 94.

After you have used the `clic_init` command or SAM, you can configure HyperFabric with MC/ServiceGuard, if necessary. See “Configuring HyperFabric with MC/ServiceGuard” on page 98 for more information.

Information You Need

When you run the `clie_init` command or use SAM for configuration, you have to provide certain configuration information. So, before you run `clie_init` or use SAM, you should get the following information:

- ❑ For each node in the fabric, determine if that node will need to interoperate with other nodes that are using; any HP-UX 10.20 version of HyperFabric, any HP-UX 11.0 HyperFabric versions earlier than B.11.00.11 or any HP-UX 11i HyperFabric versions earlier than B.11.11.01.
- ❑ For each HyperFabric adapter installed in the local node:
 - ✓ The adapter's IP address.

IMPORTANT: The last 10 bits of each adapter's IP address must be unique throughout the entire fabric. And, remember that the last part of the address cannot be 0 (that is, the IP address cannot be *n.n.n.0*). Also, note that HyperFabric converts these 10 bits to a decimal value called the **Virtual Route Identifier (VRID)**, which is used in some HyperFabric command input and output.
 - ✓ The subnet mask. When you run `clie_init` or use SAM, if you do not specify a value for this, a default subnet mask is chosen based on the adapter's IP address.

When `clie_init` begins to prompt you for the information for each adapter, it assigns an ID (for example, `clie0`) to that adapter and displays it as part of the first prompt. If you use SAM, it assigns the adapter an ID and displays it in the "Adapter Name" column of the "Configure HyperFabric Adapter" screen. Note that you can also determine an adapter's ID by running the `clie_stat` command (see "The `clie_stat` Command" on page 91). You should note each adapter's ID, because it is used as input to other HyperFabric commands.

- ❑ For each HyperFabric switch in the fabric (if you are going to enable switch management):
 - ✓ The IP address of the switch.
 - ✓ The MAC address of the switch's Ethernet port. If you do not already know the switch's MAC address, it is printed on a label on the back of the HF switch and on the front of the HF2 switch.

IMPORTANT: Remember, you cannot enable switch management through SAM—you must use the `clie_init` command.

When `clie_init` begins to prompt you for the information for each switch, it assigns an ID (for example, `sw_clie0`) to that switch and displays it as part of the first prompt. Note that you can also determine a switch's ID by running the `clie_stat` command (see "The `clie_stat` Command" on page 91). You should note each switch's ID, because it is used as input to other HyperFabric commands.

- ❑ For the entire fabric, you need the IP multicast address that all the switches and nodes in the fabric will register to. The address must be a class D address. Note that if you do not have switch management enabled, you do not need this information (`clie_init` will not prompt you for it).

- ❑ For each node in the fabric, you need the IP address of the node's Ethernet LAN interface that is on the same subnet as the switches. (As mentioned earlier, a node might have multiple LAN interfaces.) Note that if you do not have switch management enabled, you do not need this information (`clac_init` will not prompt you for it).

As stated earlier, we recommend that you do not enable switch management.

IMPORTANT


You should also check your `/etc/hosts` file—when you are using files for host name look up—to ensure that the entries for all of the systems are in the correct format: the official host name, which is the full domain extended host name, and any alias names. For example:

```
IP_address    bently6.corp3.com    bently6
IP_address    bently4.corp7.com    test1
IP_address    bently2.corp4.com    test3
```

Configuration Information Example

For this example, we have added some “dummy” (that is, not valid) addresses to the components in Figure 4-1, Map for Configuration Information Example, below. The “dummy” addresses are used only to show the flow of the information provided as input to the clic_init command and SAM. Do not try to use these addresses in your configuration.

Figure 4-1 Map for Configuration Information Example



Using the configuration information in Figure 4-1 above, the information you would specify when you run clic_init or SAM on each of the nodes is listed below. Note that this example is not an exact depiction of the prompts produced by clic_init nor the fields in SAM, but merely an example of the flow of information input. Also, remember that you should not try to use the “dummy” addresses in your actual configuration.

On node A:

1. How many HyperFabric adapters are installed on the node?
2. Do you want this node to interoperate with nodes running any HyperFabric 10.20 version or HyperFabric versions earlier than B.11.00.11 or B.11.11.01?
3. What is the IP address of the first adapter (clic0)? (192.0.0.1)

4. What is the subnet mask of the first adapter? (255.255.255.0)

If you do not specify a value for this, a default mask is chosen. You will most likely just accept the default. However, in this example, we are showing a value for the subnet mask just to illustrate the correlation between the “dummy” information in Figure 4-1 and where that information is specified or generated during `clie_init` and SAM.

5. What is the IP address of the second adapter (`clie1`)? (192.0.8.3)

6. What is the subnet mask of the second adapter? (255.255.225.0)

7. Do you want to enable switch management? Remember, you cannot enable switch management through SAM (you must use the `clie_init` command).

As stated earlier, we recommend that you do not enable switch management.

However, if you do enable it, you must provide the information in items 8 through 14:

8. If switch management has been enabled, how many switches will be configured? As stated earlier, we recommend that you do not enable switch management.

9. What is the IP address of the first switch (`sw_clie0`)? (193.0.0.20)

10. What is the Ethernet hardware address of the first switch? (0060b0d00257)

11. What is the IP address of the second switch (`sw_clie1`)? (193.0.0.21)

12. What is the Ethernet hardware address of the second switch? (0060b0d00256)

13. What is the Multicast address for the switches to use? (226.10.1.1)

14. What is the IP address for the LAN card on the same subnet as the switches? (193.0.0.10)

(Looking at Figure 4-1, this is the IP address for `lan0` on node A.)

On node B:

1. How many HyperFabric adapters are installed on the node?

2. Do you want this node to interoperate with nodes running any HyperFabric 10.20 version or HyperFabric versions earlier than B.11.00.11 or B.11.11.01?

3. What is the IP address of the first adapter (`clie0`)? (192.0.0.2)

4. What is the subnet mask of the first adapter? (255.255.255.0)

If you do not specify a value for this, a default mask is chosen. You will most likely just accept the default. However, in this example, we are showing a value for the subnet mask just to illustrate the correlation between the “dummy” information in Figure 4-1 and where that information is specified or generated during `clie_init` and SAM.

5. What is the IP address of the second adapter (`clie1`)? (192.0.8.4)

6. What is the subnet mask of the second adapter? (255.255.225.0)

7. Do you want to enable switch management? Remember, you cannot enable switch management through SAM (you must use the `clie_init` command).

As stated earlier, we recommend that you do not enable switch management.

However, if you do enable it, you must provide the information in items 8 through 14 below.

8. If switch management has been enabled, how many switches will be configured? As stated earlier, we recommend that you do not enable switch management.
9. What is the IP address of the first switch (`sw_cli0`)? (193.0.0.20)
10. What is the Ethernet hardware address of the first switch? (0060b0d00257)
11. What is the IP address of the second switch (`sw_cli1`)? (193.0.0.21)
12. What is the Ethernet hardware address of the second switch? (0060b0d00256)
13. What is the Multicast address for the switches to use? (226.10.1.1)
14. What is the IP address for the LAN card on the same subnet as the switches?
(193.0.0.11)
(Looking at Figure 4-1, this is the IP address for `lan0` on node B.)

Doing the Configuration

As explained in “Configuration Overview” on page 85, you must create the global configuration file (`/etc/rc.config.d/clic_global_conf`) on each node in the fabric. This consists mostly of specifying HyperFabric adapter-related information. (Note that if you are also going to enable switch management—which we do not recommend doing—you need to specify additional configuration information.)

NOTE

Specifying configuration information adds or changes only the addresses and other information in the global configuration file, based on the information you supply. It does not perform any operations to check the relationships between that information and any physical connections within the fabric.

You need to create the global configuration file in the following situations:

- You have just installed the HyperFabric hardware and software on the system.
- You want to change the information in the HyperFabric global configuration file (see the Note above).

IMPORTANT

Creating the global configuration file also modifies the `/etc/rc.config.d/netconf` file, adding some HyperFabric-related lines that end with the characters `#clic`. These lines are used by the HyperFabric software—and are not comments—so do not remove them from the file.

You can create the global configuration file by using (1) the `clic_init` command (described in the next section, “Using the `clic_init` Command”) or (2) SAM (described in “Using SAM—HP-UX 11.0 and HP-UX 11i” on page 94). You cannot enable card pair or switch management through SAM (you must use the `clic_init` command).

Using the clic_init Command

Run the `clic_init` command to create the global configuration file.

IMPORTANT

If the global configuration file already exists and you are running `clic_init` again (to change the file), you have the option of retaining or modifying the existing configuration information, in addition to adding new information pertaining to new hardware.

Also, once you've completed your changes and `clic_init` ends its processing, you must stop HyperFabric (by running the `clic_shutdown` command or using SAM) and then start HyperFabric (by running the `clic_start` command or using SAM). Otherwise, your configuration information changes will not take effect. See "Stopping HyperFabric" on page 99 and "Starting HyperFabric" on page 85 for more information.

If you include `/opt/clic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/clic/bin` as part of the command name (that is, `/opt/clic/bin/clic_init`).

You must be logged in as `root` to run this command.

The syntax is as follows:

```
clic_init [-c] [-?]
```

where

- `-c` specifies that you want to create the global configuration file. You are prompted for the information described in "Information You Need" on page 86. Note that if the global configuration file already exists (for example, when you are adding an adapter to an existing fabric), `clic_init` prompts you with the existing configuration information. As you are prompted with each piece of information, you can then confirm that you want to keep it or you can change it.
- `-?` displays the online help for `clic_init`.

If you do not specify any of the above parameters, the online help for `clic_init` is displayed.

After you have entered the information for all the adapters in the node and all of the switches (if any) in the fabric, a summary of the configuration information is displayed.

Once `clic_init` has finished, you do one of the following things:

- If you want to configure HyperFabric with MC/ServiceGuard, complete the configuration described in "Configuring HyperFabric with MC/ServiceGuard" on page 98, then run `clic_start` or use SAM to start HyperFabric.
- If you have just created the global configuration file on the local node for the first time (and you are not configuring MC/ServiceGuard), run `clic_start` or use SAM to start HyperFabric.
- If you have just changed an existing configuration file on the node, run `clic_shutdown` or use SAM to stop HyperFabric, and then run `clic_start` or use SAM to start HyperFabric. Until you do those two things, your configuration changes will not take effect.

See "Stopping HyperFabric" on page 99 and "Starting HyperFabric" on page 85 for more information.

Examples of clic_init

Some examples of using the clic_init command are shown below.

- Example 1

To create the global configuration file on the local node, issue this command:

```
clic_init -c
```

- Example 2

To display the online help for the clic_init command, issue this command:

```
clic_init -?
```

or this command:

```
clic_init
```

Using SAM—HP-UX 11.0 and HP-UX 11i

This section describes how to use SAM to configure HyperFabric.

IMPORTANT

If the global configuration file already exists, and you are running SAM again (to change the file), you can keep or modify the existing configuration information, in addition to adding new information pertaining to new hardware.

Also, once you've completed your changes and SAM ends its processing, you must stop HyperFabric (by running the `clic_shutdown` command or using SAM) and then start HyperFabric (by running the `clic_start` command or using SAM). Otherwise, your configuration information changes will not take effect. See “Stopping HyperFabric” on page 99 and “Starting HyperFabric” on page 85 for more information.

To use SAM to create the global configuration file on an HP 9000 system running HP-UX 11.0 or 11i, follow these steps:

Step 1. Start SAM.

Step 2. Select the “Networking and Communications” area.

Step 3. Select “HyperFabric.”

All HyperFabric adapters installed in the system are listed; installed adapters that are not yet configured show `Not Configured` in the “Status” field.

Step 4. Highlight the adapter you want to configure.

Step 5. Pull down the “Actions” menu and select `Configure Adapter`.

Step 6. In the “Configure HyperFabric Adapter” screen, specify information for the following fields:

- `Internet Address`—Required. The IP address of the adapter.
- `Subnet Mask`—Optional. The adapter's subnet mask. If you do not specify this, a default mask is chosen based on the adapter's IP address.
- `Interoperability Enabled`—Required. Whether you want the adapter to be able to interoperate with adapters that are using; any HP-UX 10.20 version of HyperFabric, any HP-UX 11.0 HyperFabric versions earlier than B.11.00.11 or any HP-UX 11i HyperFabric versions earlier than B.11.11.01. Note that if you select `No`, the HyperFabric software on the system will not be backwards compatible with previous releases. This means you must update all of the other systems in the fabric to the version that is running on the system.

Default: `No`.

Step 7. Select `OK` (remember, you cannot enable switch management within SAM).

Step 8. Exit SAM.

Once SAM has finished, you do one of the following things:

- If you want to configure HyperFabric with MC/ServiceGuard, complete the configuration described in “Configuring HyperFabric with MC/ServiceGuard” on page 98, then run `clic_start` or use SAM to start HyperFabric.

- If you have just created the global configuration file on the local node for the first time (and you are not configuring MC/ServiceGuard), run `clic_start` or use SAM to start HyperFabric.
- If you have just changed an existing configuration file on the node, run `clic_shutdown` or use SAM to stop HyperFabric, and then run `clic_start` or use SAM to start HyperFabric. Until you do those two things, your configuration changes will not take effect.

See “Stopping HyperFabric” on page 99 and “Starting HyperFabric” on page 85 for more information.

Deconfiguring a HyperFabric Adapter with SAM—HP-UX 11.0 and 11i Only

To use SAM to deconfigure a HyperFabric adapter on an HP 9000 system running HP-UX 11.0 or 11i, follow these steps:

Step 1. Start SAM.

Step 2. Select the “Networking and Communications” area.

Step 3. Select “HyperFabric.”

All HyperFabric adapters installed in the system are listed. Installed adapters that are configured show `Configured` in the “Status” field, and installed adapters that are not yet configured show `Not Configured` in the “Status” field. You can deconfigure only an adapter with a status of `Configured`.

Step 4. Highlight the adapter you want to deconfigure.

Step 5. Pull down the “Actions” menu and select `Deconfigure Adapter`.

Step 6. In the pop-up window, if you want to deconfigure the adapter, select `OK` to confirm it.

If you do not want to deconfigure the adapter, select `Cancel`.

Step 7. If you selected `OK`, the entry for the adapter is deleted from the HyperFabric configuration files (`/etc/rc.config.d/clic_global_conf` and `/etc/rc.config.d/netconf`).

If you selected `Cancel`, you remain in the main “HyperFabric Configuration” screen.

Step 8. Exit SAM.

Configuring the HyperFabric EMS Monitor

Starting with the December 2000 releases B.11.00.11 and B.11.11.01,

the HyperFabric Event Monitoring Service (EMS) monitor allows system administrators to separately monitor each HyperFabric adapter on every node in the fabric, in addition to monitoring the entire HyperFabric subsystem.

The monitor can inform the user if the resource being monitored is UP or DOWN. The administrator defines the condition to trigger a notification (usually a change in interface status). Notification can be accomplished with a SNMP trap or by logging into the syslog file with a choice of severity, or by email to a user defined email address.

To configure the HyperFabric EMS monitor, it is necessary to have the EMS HA monitor product installed (Product Number B7609BA). This product is available on the applications CD media.

Use SAM to initiate monitoring of any particular HyperFabric resource. following the procedure outlined below:

1. Start SAM (Use the online help at any time for details)
2. Select "Resource Management"
3. Select "Event Monitoring Service"
4. Select "Action" and "Add Monitoring Request"
5. Select the location /net/interfaces/clic (class for HyperFabric resources)
6. Select a resource instance (either all instances or a specific instance from the list)
7. Validate your choice by clicking on OK at the bottom of the screen
8. A Monitoring Request Parameters window opens, showing the resource and its status (if All instances have been selected, then no value is displayed)
9. Define a condition that will trigger a notification (for instance, "When Value is", "equal to", "UP")
10. Define a polling interval (default is 300 seconds)
11. Define a way of notification: SNMP trap, log in syslog with a choice of severity, or email to a user defined email address
12. Validate by pressing OK

NOTE

Although EMS is able to monitor each HyperFabric adapter on every node in the fabric, as well as the entire HyperFabric subsystem, EMS is not able to monitor HyperFabric switches.

For more detailed information on EMS, including instructions for implementing this feature, see the *EMS Hardware Monitors Users Guide Part Number B6191-90028* September 2001 Edition.

Configuring HyperFabric with MC/ServiceGuard

HyperFabric supports the MC/ServiceGuard HA product.

NOTE

If you plan to configure HyperFabric with MC/ServiceGuard, please read this section. Otherwise, skip this section and go on to the next chapter, Chapter 4, “Managing HyperFabric,” on page 83.

MC/ServiceGuard lets you create HA clusters of HP 9000 server systems. Within the cluster, MC/ServiceGuard allows you to group your application services (individual HP-UX processes) into packages. In the event of a single service, node, network, or other resource failure, MC/ServiceGuard can transfer control of the package to another node in the cluster, allowing services to remain available with minimal interruption.

CAUTION

When applications use HMP to communicate between HP 9000 nodes in a HyperFabric cluster, the EMS monitor in conjunction with MC/ServiceGuard can be configured to identify node failure and automatically fail-over to a functioning HP 9000 node. Although failure of an adapter card or a link will be detected, there will not be automatic fail-over if an adapter card or a link fails. See “Features” on page 25 for details on features available when HMP applications are run over HyperFabric.

MC/ServiceGuard directly monitors cluster nodes, LAN interfaces, and services, which are the individual processes within an application. In addition, specialized monitors might be supplied by the developers of other components. The HyperFabric monitor is supplied with the HyperFabric product and is installed with it. To use the HyperFabric monitor with MC/ServiceGuard, you configure the monitor as an MC/ServiceGuard package dependency.

Although HyperFabric can be used by an application within a package to communicate with other nodes, it is not possible to use HyperFabric as a heartbeat LAN. So, in a package control script, do not specify HyperFabric IPs/subnets in the lines that contain the keywords `IP[n]` and `SUBNET[n]`. Also, `cmquerycl` will not “discover” and report HyperFabric IPs and subnets.

After you have configured HyperFabric as a package dependency, MC/ServiceGuard's package manager calls the **Event Monitoring Service (EMS)** to launch an external monitor for HyperFabric. The package will not start unless the monitor reports that HyperFabric is available, and the package will fail when HyperFabric's status is DOWN (that is, when all HyperFabric adapters on a node become non-functional).


Complete instructions for configuring MC/ServiceGuard clusters and packages are provided in *Managing MC/ServiceGuard*.

Figure 4-2 below shows a HyperFabric switch configuration with MC/ServiceGuard. This example shows a four-node configuration with two HyperFabric switches, and redundant heartbeat Ethernet LANs.

NOTE

Because the HyperFabric network does not currently support MC/ServiceGuard heartbeat connections, you must use an alternative type of connection for the heartbeat, such as FDDI, Token Ring, 100BaseT, or Ethernet (as shown in Figure 4-2 below).

Figure 4-2 **An MC/ServiceGuard Configuration (with Two HyperFabric Switches)**



How HyperFabric Handles Adapter Failures

HyperFabric adapters are handled differently than other types of networking adapters (such as Ethernet, FDDI, and Fibre Channel) in the MC/ServiceGuard environment. In the non-HyperFabric cases, two network links are in a node, and one will be active and one will be idle or in standby. In the case of an active link failure, MC/ServiceGuard is notified and the network traffic is switched to the standby adapter (which then becomes active).


However, in the case of HyperFabric, if two adapters are in a node, both will be active. If one active HyperFabric adapter fails, its network traffic is switched to the other active HyperFabric adapter in the node. (Throughput might be slower because only one active

adapter is now handling the network traffic.) This rearrangement is handled by the HyperFabric software, and MC/ServiceGuard is not notified. However, note that if all of the HyperFabric adapters fail, HyperFabric does notify MC/ServiceGuard. In both cases, though, the events are logged to `/var/adm/clic_log` and `/var/adm/syslog.log`.

Example 1:

This example, illustrated by Figure 4-3 below, presents an HA configuration using MC/ServiceGuard with HyperFabric. Both of the HyperFabric adapters are active on node A. The HyperFabric Resource Monitor reports the active status of the HyperFabric resource to the Event Monitoring Service (EMS), which lets MC/ServiceGuard know that the HyperFabric resource is available to Packages A and B.


Figure 4-3 **Node with Two Active HyperFabric Adapters**



Example 2:

This example, illustrated by Figure 4-4 below, shows the same node after the failure of one of the HyperFabric adapters. The remaining adapter in node A is now handling all HyperFabric network traffic for the node. Because the HyperFabric resource is still available, MC/ServiceGuard has not been notified; HyperFabric handles the local HyperFabric adapter failover. However, the failure of adapter 1 has been logged to `/var/adm/clic_log`.

Figure 4-4 Node with One Failed HyperFabric Adapter




After the failover, if you issue a `netstat -in` command, you will see that an IP address is still assigned to each adapter. For example:

Name	MTU	network	Address	Ipkts	Opkts
clic1	31744	172.16.10.0	172.16.10.11	711	12
clic0	31744	172.16.20.0	172.16.20.21	1222	333

Example 3:

This final example, illustrated by Figure 4-5 below, shows a situation in which all of the HyperFabric adapters on node A fail. The HyperFabric Resource Monitor reports to the Event Monitoring Service (EMS). The EMS then notifies the MC/ServiceGuard `cmcl` daemon that the HyperFabric resource on node A is unavailable. Because HyperFabric is configured as a package dependency for Packages A and B, MC/ServiceGuard causes the packages to failover to node B. In a four-node configuration (note that only two nodes are shown in Figure 4-5 below), Packages A and B can continue to communicate through the HyperFabric network with the other active nodes in the MC/ServiceGuard cluster.

Figure 4-5 When All HyperFabric Adapters Fail



Configuring HyperFabric with the MC/ServiceGuard Resource Monitor

You can configure the HyperFabric Resource Monitor with MC/ServiceGuard in either of these ways:

- Editing an ASCII file.
- Using the SAM GUI.

For more details, please see the manual *Using EMS HA Monitors*.

NOTE

You should configure HyperFabric with MC/ServiceGuard before running the `clic_start` command or using SAM to start HyperFabric.

Configuring MC/ServiceGuard with HyperFabric Using the ASCII File

When using the MC/ServiceGuard commands (for example, `cmapplyconf`) to specify the use of the HyperFabric Resource Monitor, the section of the package ASCII configuration file that has the keyword `RESOURCE_NAME` must be uncommented and set to the following values:

```
RESOURCE_NAME                /net/interfaces/clic/status

RESOURCE_POLLING_INTERVAL    10

RESOURCE_UP_VALUE             =UP
```

Configuring MC/ServiceGuard with HyperFabric Using SAM

You must perform the following steps when using SAM to configure the HyperFabric Resource Monitor with MC/ServiceGuard:

```
sam
Clusters
  High Availability Clusters
    Cluster Configuration (go through all the steps to create a
    cluster)
    Package Configuration
      Create/Add Package (if creating new packages)

        Specify Package Name and Nodes
        Specify Package SUBNET Address
        Specify Package Services
        Specify Package Failover Options
        Specify Package Control Script Location
        Specify Package Control Script Information

      Specify Package Resources Dependencies
      Add
        Resource Name
        (Navigate the Resource Subclass by double-clicking on
        /net until /net/interfaces/clic/ status shows up in the
        selection box Resource Name, then select it and click OK.)

Resource Parameters

- Input the Resource Polling Interval (for example, 10 seconds).

- Select "UP" from the "Available Resource Values" and click "Add".

- Click OK to accept the values.
```

Configuring MC/ServiceGuard for HyperFabric Relocatable IP Addresses

If you are using HyperFabric version B.11.00.05, B.11.11.00, or later (note no HP-UX 10.20), and you want to use relocatable IP addresses, configure the relocatable IP addresses with the `IP[n]` command in the package control script.

For example, to configure the relocatable address `192.0.0.3` for adapter 0 and `192.0.8.5` for adapter 1, specify this:

```
IP[0]= 192.0.0.3
```

```
IP[1]= 192.0.8.5
```

4 Managing HyperFabric

This chapter contains the following sections that give information about managing HyperFabric:

- “Starting HyperFabric” on page 85
- “Verifying Communications within the Fabric” on page 87

- “Displaying Status and Statistics” on page 91
- “Viewing man Pages” on page 98
- “Stopping HyperFabric” on page 99

Starting HyperFabric

HyperFabric is started in one of these three ways:

- As part of the normal local node boot process (HP 9000 system).
- By running the HyperFabric `clic_start` command (described below).
- By starting HyperFabric through SAM (described in “Using SAM—HP-UX 11.0 and 11i Only” on page 86).

HyperFabric needs to be started in the following situations:

- If HyperFabric hardware and software have just been installed on the system and the `clic_init` command has been used to configure the HyperFabric adapters on this node.
- If the HyperFabric configuration has been changed by using the `clic_init` command or using SAM (HP-UX 11.0 and 11i Only). In this situation, you must have run `clic_shutdown` or used SAM to stop HyperFabric (HP-UX 11.0 and 11i Only), before restarting HyperFabric.
- If a new HyperFabric adapter has been added to a system online and configured using `clic_init`. In this situation, it is not necessary to run `clic_shutdown` before running `clic_start` (see “Online Addition and Replacement—HP-UX 11i Only” on page 55 in Ch. 3 of this user guide).

NOTE

Starting HyperFabric launches the HyperFabric CLuster InterConnect (CLIC) daemon (`clic_mgmtd`). This daemon process must be running for the HyperFabric product to operate correctly. It is possible that other daemons will be running, but it is essential that at least one CLIC daemon is running. To check if a CLIC daemon is running, use the following command:

```
ps -ef | grep clic
```

If the CLIC daemon is not running, start the HyperFabric subsystem by executing the following command:

```
/opt/clic/bin/clic_start
```

Using the `clic_start` Command

Run the `clic_start` command on each node to start the HyperFabric management process on that node.

If you include `/opt/clic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/clic/bin` as part of the command name (that is, `/opt/clic/bin/clic_start`).

You must be logged in as `root` to run this command.

The syntax is as follows:

```
clic_start
```

The `clic_start -?` command can be issued to display the online help for `clic_start`, or look at the `clic_start (1m)` man page by issuing the `man clic_start` command.

If HyperFabric is already running, you will receive an informational (FYI) message telling you so. Your reaction to this message depends on the situation:

- If you have simply forgotten (or did not know) that HyperFabric was already running, you do not have to do anything.
- If you have changed the HyperFabric configuration with the `clic_init` command or SAM, you must stop HyperFabric (by running the `clic_shutdown` command or using SAM) and then start HyperFabric (by running the `clic_start` command or using SAM). See either “Using the `clic_shutdown` Command” on page 99 or “Using SAM—HP-UX 11.0 and 11i Only” on page 100, whichever is appropriate.

Using SAM—HP-UX 11.0 and 11i Only

To use SAM to start HyperFabric on an HP 9000 system running HP-UX 11.0 or 11i, follow these steps:

- Step 1.** Start SAM.
- Step 2.** Select the “Networking and Communications” area.
- Step 3.** Select “HyperFabric.”
- Step 4.** Pull down the “Actions” menu and select `Start HyperFabric`. Note that with a HP-UX 11.0 operating system, if HyperFabric is already running, `Start HyperFabric` is grayed out and cannot be selected. With a HP-UX 11i operating system, if HyperFabric is already running, `Start HyperFabric` is not grayed out. With HP-UX 11i the newly added adapter can be configured and started (using OLA), without doing a `clic_shutdown` or a `clic_start` on the node.

When HyperFabric starts, a confirmation message displays. Also, the status “HyperFabric: Running” is displayed above the adapter configuration area of the screen.

- Step 5.** Exit SAM.

Verifying Communications within the Fabric

You can verify the communications within the fabric by running the `cllic_probe` command, which is described below. You can also use `cllic_probe` to verify the status of specific adapters.

NOTE

Beginning with HyperFabric versions B.11.00.11 and B.11.11.01, `cllic_probe` replaces the `cllic_ping` command. For systems running HP-UX 10.20, use `cllic_ping` (see the `cllic_ping` man page for information about the command).

IMPORTANT

You should also check your `/etc/hosts` file—when you are using files for host name look up—to ensure that the entries for all of the systems are in the correct format: the official host name, which is the full domain extended host name, and any alias names. For example:

```
IP_address    bently6.corp3.com    bently6
IP_address    bently4.corp7.com    test1
IP_address    bently2.corp4.com    test3
```

The `cllic_probe` Command

Run the `cllic_probe` command to send 256-byte packets to verify the link out to and back from a specific destination, optionally using a specific adapter for the verification. The destination can be either a node or a switch (if a switch is part of the fabric).

If you include `/opt/cllic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/cllic/bin` as part of the command name (that is, `/opt/cllic/bin/cllic_probe`).

You do not have to be logged in as `root` to run this command.

The syntax is as follows:

```
cllic_probe node_name [-c adapter_ID]
                  [-c adapter_ID -r VRID switch_hopcount]
                  [-l -c adapter_ID] [-s -c adapter_ID]
                  [-p packet_count] [-?]
```

Note that some of the lines in the above syntax are indented for readability purposes only. When you actually type the command, you do not indent anything.

The command parameters are as follows:

- `node_name` specifies the node you want to verify. This value is conditionally required—you must specify it when you are verifying traffic to a remote node, unless you use the `-r` parameter (described below).
- `-c` specifies that you want to use the adapter identified by `adapter_ID` for the verification.

- `-r` specifies that *VRID switch_hopcount* is the routing information for the adapter. To determine the *VRID* and *switch_hopcount* to specify, first run the `clic_stat -d VRID` command (see “The clic_stat Command” on page 91). Note that if you specify this parameter (`-r VRID switch_hopcount`), you must also specify the `-c adapter_ID` parameter (described above).
- `-l` specifies that you want to do local loopback testing on a particular adapter. Note that if you specify this parameter (`-l`), you must also specify the `-c adapter_ID` parameter (described above).
- `-s` specifies that you want to loopback at the switch port attached to a particular adapter. Note that if you specify this parameter (`-s`), you must also specify the `-c adapter_ID` parameter (described above).
- `-p` specifies that you want to send *packet_count* number of 256-byte packets. *packet_count* can be any positive integer. This parameter is useful for building scripts for debugging or for hardware verification. If you do not specify this parameter, one packet is sent each second, until you stop the command with a **CTRL-C**.
- `-?` displays the online help for `clic_probe`.

If you do not specify any of the above parameters, the online help for `clic_probe` is displayed.

NOTE

Also see the `cllic_diag` command to:

Probe a specific remote node.

Dump and format trace data.

Set the tracing level for the HyperFabric software and firmware.

The `cllic_diag` command is detailed in the Running Diagnostics section of Chapter 6, *Troubleshooting*.

Examples of `cllic_probe`

Some examples of using `cllic_probe` are shown below.

- **Example 1**

If the local node is `bently6` and you want to send five packets to verify that the adapter `cllic0` (which is on `bently6`) is able to handle traffic, issue this command:

```
cllic_probe -l -c cllic0 -p 5
```

The generated output could look like this:

```
CLIC_PROBE: 256 byte packets
Local Loopback: Source and Target Adapter ID: bently6.corp3.com:cllic0

256 bytes:      seq_num = 1.      Packet Acknowledged.
256 bytes:      seq_num = 2.      Packet Acknowledged.
256 bytes:      seq_num = 3.      Packet Acknowledged.
256 bytes:      seq_num = 4.      Packet Acknowledged.
256 bytes:      seq_num = 5.      Packet Acknowledged.
----- bently6.corp3.com CLIC_PROBE Statistics -----
5 packets transmitted, 5 packets received, 0% packet loss.
```

- **Example 2**

If the local node is `bently6`, and you want to verify communications with the remote node `bently4`, issue this command:

```
cllic_probe bently4
```

```
CLIC_PROBE: 256 byte packets
Source adapter id: bently6.corp3.com:cllic0
Target adapter id: bently4.corp7.com:cllic3

256 bytes:      seq_num = 1.      Packet Acknowledged.
256 bytes:      seq_num = 2.      Packet Acknowledged.
256 bytes:      seq_num = 3.      Packet Acknowledged.
256 bytes:      seq_num = 4.      Packet Acknowledged.
256 bytes:      seq_num = 5.      Packet Acknowledged.
256 bytes:      seq_num = 6.      Packet Acknowledged.
256 bytes:      seq_num = 7.      Packet Acknowledged.
256 bytes:      seq_num = 8.      Packet Acknowledged.
----- bently6.corp3.com CLIC_PROBE Statistics -----
8 packets transmitted, 8 packets received, 0% packet loss.
```

- **Example 3**

If the local node is `bently6`, and you want to send five packets to verify communications with the remote node `bently7`, using the adapter `cllc0` (which is on `bently6`), issue this command:

```
cllc_probe bently7 -c cllc0 -p 5
```

```
CLIC_PROBE: 256 byte packets
  Source adapter id: bently6.corp3.com:cllc0
  Target adapter id: bently7.corp4.com:cllc1

256 bytes:      seq_num = 1.      Packet Acknowledged.
256 bytes:      seq_num = 2.      Packet Acknowledged.
256 bytes:      seq_num = 3.      Packet Acknowledged.
256 bytes:      seq_num = 4.      Packet Acknowledged.
256 bytes:      seq_num = 5.      Packet Acknowledged.
----- bently7.corp4.com CLIC_PROBE Statistics -----
5 packets transmitted, 5 packets received, 0% packet loss.
```

- **Example 4**

If the local node is `bently6`, and you want to send five packets to verify communications with the remote node `bently7`, using the adapter `cllc0` (which is on `bently6`) and the route identified by VRID 194 and switch hopcount 1, issue this command:

```
cllc_probe -c cllc0 -r 194 1 -p 5
```

(Remember, because you specified the `-r VRID switch_hopcount` parameter, you do not need to also specify the `node_name`.)

The generated output could look like this:

```
CLIC_PROBE: 256 byte packets sent
  Source adapter id: bently6.corp3.com:cllc0
  Target adapter id: bently7.corp4.com:cllc1

256 bytes:      seq_num = 1.      Packet Acknowledged.
256 bytes:      seq_num = 2.      Packet Acknowledged.
256 bytes:      seq_num = 3.      Packet Acknowledged.
256 bytes:      seq_num = 4.      Packet Acknowledged.
256 bytes:      seq_num = 5.      Packet Acknowledged.
----- bently7.corp4.com CLIC_PROBE Statistics -----
5 packets transmitted, 5 packets received, 0% packet loss.
```

Note that the VRID you specified (194) actually went to the adapter `cllc1` on `bently7`. And, as explained earlier, you run the `cllc_stat -d VRID` command to determine the VRID and switch hopcount to specify.

Displaying Status and Statistics

You can get the status of and statistics associated with many of the HyperFabric components by using the `clic_stat` command, which is described below.

The `clic_stat` Command

The following list contains some of the information that the `clic_stat` command will provide:

- The current fabric map, in textual format.
- The status of one or more HyperFabric adapters.
- The global configuration information for each HyperFabric adapter and switch (if the fabric contains switches). The information includes the firmware type (8-bit or 32-bit), which is used for interoperability purposes.

The `clic_stat` command can also be used to enable or disable performance statistics gathering for the DLPI driver, the firmware and HMP.

All of the statistics that can be displayed using the `clic_stat` command are documented in the `clic_stat (1M)` man page on HP-UX 11.0 and on later HP-UX releases.

If you include `/opt/clic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/clic/bin` as part of the command name (that is, `/opt/clic/bin/clic_stat`).

To use some of this command's parameters, you must be logged in as `root` (see each parameter's description below).

The syntax is as follows:

```
clic_stat [-p perf_level] [-d display_level] [-c adapter_ID]
          [-n nodename] [-?]
```

Note that the second line in the above syntax is indented for readability purposes only. When the command is typed there should not be any indentation.

The command parameters are as follows:

- `-p` enables/disables performance statistics gathering according to the value of *perf_level*, which is one of the following:

TCP	Enables DLPI driver statistics when under the TCP/IP stack.
HMP	Enables Hyper Messaging Protocol (HMP) statistics gathering.
FW	Enables firmware statistics gathering.
RST	Disables/resets the DLPI driver and HMP statistics.

Note that turning on performance statistics gathering will affect the performance of HyperFabric, by increasing CPU usage and message latency (the time it takes a message to get from one point to another). It might also decrease the throughput of data. It is recommended that you do not specify this parameter unless you are trying to troubleshoot HyperFabric problems.

You must be logged in as `root` to use this parameter.

- `-d` specifies that you want to set the level of data displayed to *display_level*, which is one of the following:

NET	Displays fabric component statistics.
CFG	Displays the management daemon (<code>clirc_mgmtd</code>) configuration and statistics data.
VRID	Displays the virtual route identifier information—the VRIDs, IP addresses, switch hopcounts, and physical routes—for each HyperFabric adapter in the local node.
ALL	Displays all available status data.

- `-c` displays the statistics of the adapter identified by *adapter_ID*.
- `-n` displays statistics for the node identified by *nodename*.
- `-s` specifies that you want to get the status of the switch identified by *switch_ID* (assigned by `clirc_init` or SAM). Note that this parameter is meaningful only if you enabled switch management (through the `clirc_init` command).

To determine the *switch_ID*, run the `clirc_stat` command without specifying any parameters. This displays each *switch_ID* known to the system. Look through the command's output to find the ID of the switch you are interested in.

- `-?` displays the online help for `clirc_stat`.

If you do not specify any of the above parameters, the current fabric map is displayed, showing the last known status of the components.

Examples of `clirc_stat`

Some examples of using `clirc_stat` are shown below.

- Example 1

If the local node is `bently7`, and you want to enable DLPI driver statistics gathering, issue this command:

```
clirc_stat -p TCP
```

The generated output could look like this:

```
=====
Date: Sat Aug 5 16:08:14 2000

Node: bently7.corp2.com

-----

Performance Statistics Levels - Possible perf degradation occurring:
    DLPI performance statistics enabled
```

- **Example 2**

If the local node is `bently7`, and you want to display the management daemon (`cllic_mgmtd`) configuration and statistics data, issue this command:

`cllic_stat -d CFG`

The generated output could look like this:

```
=====
Date: Sat Aug 5 16:08:12 2000

Node: bently7.corp2.com

-----

=====
      CLIC Management Global Status/Statistics
      Current Component Versions
CLIC Management process version:      1.0
CLIC Management API version:         1.0
CLIC Driver version:                  1.0
      Global Management Statistics
Node failures:                        0
Nodes active:                        0
Command session failures:             0
Command active sessions:              1
Command total sessions:               6
Management mesh session failures:     0
Management mesh active sessions:      0

Management Global Interval Timers
Fabric mapping interval (ms):         60000

Performance Statistics Levels - Possible perf degradation occurring:
      DLPI performance statistics enabled
=====
```

- **Example 3**

If the local node is `bently7`, and you want to display the statistics for the adapter `cllic1` (which is on `bently7`), issue this command:

`cllic_stat -c cllic1`

The generated output could look like this:

Managing HyperFabric

Displaying Status and Statistics

```
=====
Date: Sat Aug 5 16:08:30 2000

Node: bently7.corp2.com

-----
Adapter ID:                  clic1
Instance Number:             1
Adapter Type:                 1X PCI or HSC
Firmware File:                /opt/clic/firmware/clic_fw_1x32c
Major Num:                    238
Mgmt process driver handle:   5
Version:                      1.0
H/W Path:                     8/4/0/0
Primary IP address:           192.0.0.9
Uptime time:                  0 days 21 hours 1 min 3 sec

Adapter State Flags Set - Multiple flags may be set:
    Configured and operational
    Switch mode

    F/W Error Statistics
Frame buffer overflow:        0
Receive on disabled endpoint: 0
Invalid endpoint ID:          0
Invalid endpoint protection key: 0
Interleaved gathered receive: 0
Interleaved multi-frame bulk messages: 0
NQ overflow:                  0
Send NQ overflow:             0
Invalid slot key for NQ credit update: 0
DLPI QOS receive buffer shortage: 0
Link congestion events:       0
Max send packet retry exceeded: 0
Link or switch failure events: 0
Link or switch resume events: 1
Bad route detected:           0
Bad optional data length:     0
Invalid message received:     0
CRC error:                    0
Invalid CRC word:             0
Bad frame length:             0
Receive buffer overflow:      0
Null packets generated on link reset: 2
Firmware reset notification:  0
Data corruption notification: 0
Unsupported QOS message received: 0
Invalid HMP VC ID:            0
Invalid HMP endpoint ID:      0
Invalid HMP endpoint protection key: 0
HMP message order violation:  0
Packet drops:                 0
Transmit side congestion events: 1
Receive side congestion events: 0
    Other Misc Statistics
Mapping message send failures: 0
=====
```

- **Example 4**

If the local node is `bently6`, and you want to display the VRIDs, IP addresses, switch hopcounts, and physical routes for each HyperFabric adapter in `bently6`, issue this command:

`clic_stat -d VRID`

The generated output if the nodes are connected in a Point-to-Point configuration could look like this:

```
=====
Date: Sat Aug 5 16:08:12 2000

Node: bently6.corp4.com

-----

Adapter : clic0

-----

VRID      IP Address      Switch Hopcount  Route Id  Physical route
-----
1         192.0.0.1       0                Point to Point Connection
2         192.0.0.2       0                Point to Point Connection
12        192.0.0.12      0                Point to Point Connection
13        192.0.0.13      0                Point to Point Connection

=====

Adapter : clic2

-----

VRID      IP Address      Switch Hopcount  Route Id  Physical route
-----
1         192.0.0.1       0                Point to Point Connection
2         192.0.0.2       0                Point to Point Connection
12        192.0.0.12      0                Point to Point Connection
13        192.0.0.13      0                Point to Point Connection

=====
```

The generated output if the nodes are connected through a switch could look like this:

```
=====
Date: Sat Aug 5 16:08:12 2000

Node: bently6.corp4.com

-----

=====

Adapter :      clic0

-----

VRID    IP Address      Switch Hopcount    Route Id    Physical route
-----
1       192.0.0.1         1                  0           0x09
2       192.0.0.2         1                  0           0x03
12      192.0.0.12        1                  0           0x06
13      192.0.0.13        1                  0           0x00

=====

Adapter :      clic2

-----

VRID    IP Address      Switch Hopcount    Route Id    Physical route
-----
1       192.0.0.1         1                  0           0x03
2       192.0.0.2         1                  0           0x3d
12      192.0.0.12        1                  0           0x00
13      192.0.0.13        1                  0           0x3a

=====
```

- **Example 5**
If the local node is bently7, and you want to disable all statistics gathering on bently7, issue this command:
clic_stat -p RST
The generated output could look like this:

```
=====
Date: Sat Aug 5 16:08:35 2000

Node: bently7.corp6.com
```



```
-----  
No performance statistics are being gathered - Reset successful  
=====
```

Viewing man Pages

If you want to be able to view the HyperFabric man pages, you must first add `/opt/clic/share/man` to your `MANPATH` environment variable. Then, to view a man page, type the following:

```
man command_name
```

For example, to view the man page for `clic_stat`, type this:

```
man clic_stat
```

Stopping HyperFabric

You can stop HyperFabric only on a local node. Stopping HyperFabric on a node makes all of the HyperFabric adapters in that node unreachable by all other nodes in the fabric. It stops the HyperFabric management process, which stops all interconnect operations on the node.

To stop HyperFabric, you use (1) the `clic_shutdown` command (described below) or (2) SAM (described in “Using SAM—HP-UX 11.0 and 11i Only” on page 100).

Note that if you stop HyperFabric, the only ways you can restart HyperFabric on the node is to (1) run the `clic_start` command (see “Using the `clic_start` Command” on page 85) or (2) use SAM (see “Using SAM—HP-UX 11.0 and 11i Only” on page 86).

Using the `clic_shutdown` Command

Run the `clic_shutdown` command to stop HyperFabric on the local node.

If you include `/opt/clic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/clic/bin` as part of the command name (that is, `/opt/clic/bin/clic_shutdown`).

You must be logged in as `root` to run this command.

The syntax is as follows:

```
clic_shutdown
```

Note that you also can issue the command `clic_shutdown -?` to display the online help for `clic_shutdown`.

Using SAM—HP-UX 11.0 and 11i Only

To use SAM to stop HyperFabric on a local HP 9000 system running HP-UX 11.0 or 11i, follow these steps:

- Step 1.** Start SAM.
- Step 2.** Select the “Networking and Communications” area.
- Step 3.** Select “HyperFabric.”
- Step 4.** Pull down the “Actions” menu and select `Stop HyperFabric`. Note that if HyperFabric is not running on the system, `Stop HyperFabric` is grayed out and you cannot select it.

When HyperFabric stops, a confirmation message displays. Also, the status “HyperFabric: Not running” is displayed above the adapter configuration area of the screen.

- Step 5.** Exit SAM.

5 Troubleshooting HyperFabric

This chapter contains these sections that describe troubleshooting HyperFabric:

- “Running Diagnostics” on page 103
- “Using Support Tools Manager” on page 108
- “Useful Files” on page 109

- “LED Colors and Their Meanings” on page 111
- “Determining Whether an Adapter or a Cable is Faulty” on page 122
- “Determining Whether a Switch is Faulty” on page 123
- “Replacing a HyperFabric Adapter” on page 125
- “Replacing a HyperFabric Switch” on page 126

Running Diagnostics

Before running HyperFabric diagnostics:

1. Confirm HyperFabric adapters are installed on each node. Use the following command to display a list of HyperFabric adapters installed each node:

```
ioscan -funC clic
```

2. Check to see if HyperFabric software is installed. Use the following command to display the HyperFabric software version installed on each node:

```
swlist | grep -i hyperfabric
```

3. Check the patch level. Use the following command to display the list of patches installed on each node:

```
swlist
```

Refer to the *HyperFabric Release Note* to determine which patches need to be installed.

4. Make sure the HyperFabric subsystem is started. Use the following command to determine if the HyperFabric subsystem is running on the node:

- ```
ps -ef | grep clic
```

If the HyperFabric daemon (`clic_mgntd`) is not running, start the HyperFabric subsystem by executing the following command:

```
/opt/clic/bin/clic_start
```

5. Make sure the correct IP addresses are assigned to the HyperFabric adapters. Use the following command to display all of the network interfaces and the IP addresses assigned to them:

```
netstat -in
```

If an IP address is not assigned to a HyperFabric adapter, execute the following commands in the order listed:

```
clic_shutdown
```

```
clic_init
```

```
clic_start
```

All of these commands reside in the `/opt/clic/bin` directory.

6. Check cabling to make sure all of the HyperFabric adapters are connected to the fabric.

7. Run the following command:

```
/opt/clic/bin/clic_stat -dALL
```

If a TCP/UDP/IP application is running:

Check the firmware file field to make sure the same version of firmware is downloaded on all of the HyperFabric adapters in the cluster. If this is not the case, run the following commands in the order listed below:

```
cllic_shutdown
```

```
cllic_init
```

(The answer to the interoperability question must be consistent on all nodes in the fabric.)

```
cllic_start
```

Check to make sure all IP addresses have been assigned.

Check the subnet. Every HyperFabric adapter in the fabric must be able to communicate with every other HyperFabric adapter.

Every HyperFabric adapter in the fabric must be connected, point-to-point or via a switch.

Run diagnostics to make sure data can be transferred on the HyperFabric adapters. Use the following command (which is detailed in the next section of this chapter):

```
— cllic_diag
```

If the HyperFabric subsystem is still not usable, contact your HP support representative with the diagnostics data generated using the `cllic_diag` command.

If an HMP application is running:

Make sure 4X HyperFabric adapters are installed on the nodes. The adapter type field indicates the type of HyperFabric adapter that is installed. HMP will only run on 4X HF1 PCI (A6092A) or 4X HF2 PCI (A6386A) adapters.

Check the firmware file field to make sure the firmware file name for each HyperFabric adapter ends in 32c. All of the HyperFabric adapters in the fabric must have firmware files that end in 32c for HMP to run. If this is not the case, run the following commands in the order listed below:

```
cllic_shutdown
```

```
cllic_init
```

(The answer to the interoperability question must be consistent on all nodes in the fabric.)

```
cllic_start
```

All of the IP addresses in the fabric must be in the same subnet. The lower 10 digits of all of the IP addresses in the fabric must be unique. Every HyperFabric adapter in the fabric must be able to communicate with every other HyperFabric adapter in the fabric.

Every HyperFabric adapter in the fabric must be connected, point-to-point or via a switch. If one of the adapters in the fabric is not connected, HMP will not be able to run.

Run diagnostics to make sure data can be transferred on the HyperFabric adapters. Use the following command (which is detailed in the next section of this chapter):

```
— cllic_diag
```



If you are running an Oracle application using HMP and traffic does not appear to be flowing after completing all of the steps listed above, check the `ORAHOME/rdbms/log/alert*log` files. The display should show Cluster Interconnect IPC version:Oracle using HP-HMP logged in the alert log files. If not, recompile the Oracle application to run using HMP according to the instructions provided in the *Oracle Installation and Administration Guide*.

Diagnostics can be run on many of the HyperFabric components by using the `clic_diag` command. If the HyperFabric subsystem is still not usable, contact your HP support representative with the diagnostics data generated using the `clic_diag` command described below.

## The clic\_diag Command

Use the `clic_diag` command to run the following diagnostics:

- Probe a specific remote node.
- Dump and format trace data.
- Set the tracing level for the HyperFabric software and the firmware.

Two versions of the `clic_diag` command are available:

- The command line version. In this version, you specify the command and the parameters you want to run (which are described below).
- The interactive version. To use this version, specify only the command name (`clic_diag`). Then, you are prompted for the same kinds of information you specify when you use the command line version.

If you include `/opt/clic/bin` in your `PATH` statement, you can run the command as it is shown below. Otherwise, you must include `/opt/clic/bin` as part of the command name (that is, `/opt/clic/bin/clic_diag`).

You must be logged in as `root` to run this command.

The command line syntax is as follows:

```
clic_diag [-r remote_node_name] [-T trace_level] [-D TCP_IP]
 [-C TCP_IP] [-B trace_buffer_size]
 [-F trace_file_size] [-d adapter_ID filename] [-?]
```

Note that some of the lines in the above syntax are indented for readability purposes only. When you actually type the command, you do not indent anything.

The command parameters are as follows:

- **-r** specifies that you want to probe a specific remote node identified by *remote\_node\_name*. The probe is done on all operational routes to the remote node.
- **-T** specifies that you want to set the tracing level for the HyperFabric software and the firmware to *trace\_level*, which can be one or more of the following (you can specify either the keyword or the hexadecimal value):

|                       |                                                                                             |
|-----------------------|---------------------------------------------------------------------------------------------|
| reset or 0x0          | Reset tracing to the default level for all components (that is, turn off all tracing).      |
| send_path or 0x0002   | Trace the HyperFabric software send path.                                                   |
| packet_data or 0x0004 | Trace the packet data.                                                                      |
| packet_hdr or 0x0008  | Trace the protocol headers (TCP/UDP/IP).                                                    |
| data_struct or 0x0010 | Trace the HyperFabric software CLIC-specific data structures and events.                    |
| rcv_path or 0x0020    | Trace the HyperFabric software receive path.                                                |
| control or 0x0040     | Trace the HyperFabric software control messages.                                            |
| all or 0xffff         | Turn on all possible trace levels. Note that this will have a severe impact on performance. |

To find out what the current tracing level is, run this parameter (**-T**) without any keyword or hexadecimal value specified.

- **-D** specifies that you want to dump the trace buffers from the kernel to a user-space file and format the data using the formatter *TCP\_IP*. The HyperFabric software trace data is dumped into the file */var/adm/clic\_ip\_drv.trc* and formatted.
- **-C** *TCP\_IP* operates in a way similar to **-D** *TCP\_IP*, except that the trace data in the kernel is dumped at regular intervals to the trace file */var/adm/clic\_ip\_drv.trc0*, and if that file gets full, to */var/adm/clic\_ip\_drv.trc1*. So, new trace events are appended to the trace output file. This stops when tracing is turned off.
- **-B** specifies that you want the size (in bytes) of the trace buffer to be *trace\_buffer\_size*. The buffer is dynamically allocated when tracing is enabled. Also, the buffer is circular, which means that when the end of the buffer is reached, the data wraps around to the beginning of the buffer (and overwrites any previous data). If you do not specify this parameter, a default buffer is created with a size of 64k bytes.
- **-F** specifies *trace\_file\_size* as the maximum size of the trace output file. For the **-D** *TCP\_IP* parameter, the file is */var/adm/clic\_ip\_drv.trc*. For the **-C** *TCP\_IP* parameter, the files are */var/adm/clic\_ip\_drv.trc0* (and if needed, */var/adm/clic\_ip\_drv.trc1*).
- **-d** dumps the memory of the adapter identified by *adapter\_ID* to the dump file *filename*. If you do not specify *filename*, the default file is */var/adm/clic\_fw.dumpx*, where *x* is the adapter instance number.
- **-?** displays the online help for *clic\_diag*.

If you do not specify any of the above parameters, the online help for *clic\_diag* is displayed.

## Example of clic\_diag

An example of the clic\_diag command is shown below.

If the local node is bently6, and you want to confirm that all of the adapters on bently6 are communicating with the target adapters on bently8, issue this command:

```
clic_diag -r bently8
```

The generated output could look like this:

```
CLIC_PROBE: 256 byte packets
 Source adapter id: bently6.corp4.com:clic0
 Target adapter id: bently8.corp2.com:clic1

256 bytes: seq_num = 0. Packet Acknowledged.
256 bytes: seq_num = 1. Packet Acknowledged.
256 bytes: seq_num = 2. Packet Acknowledged.
256 bytes: seq_num = 3. Packet Acknowledged.
256 bytes: seq_num = 4. Packet Acknowledged.
----- CLIC_PROBE Statistics -----
5 packets transmitted, 5 packets received, 0% packet loss.
CLIC_PROBE: 256 byte packets
 Source adapter id: bently6.corp4.com:clic1
 Target adapter id: bently8.corp2.com:clic3

256 bytes: seq_num = 0. Packet Acknowledged.
256 bytes: seq_num = 1. Packet Acknowledged.
256 bytes: seq_num = 2. Packet Acknowledged.
256 bytes: seq_num = 3. Packet Acknowledged.
256 bytes: seq_num = 4. Packet Acknowledged.
----- CLIC_PROBE Statistics -----
5 packets transmitted, 5 packets received, 0% packet loss.
```

## Using Support Tools Manager

Use **Support Tools Manager (STM)** with HyperFabric to gather information about HyperFabric components and to diagnose hardware problems.

Two tools are available in STM for HyperFabric:

- The Information Tool provides information about the HyperFabric adapter, without resetting the adapter.
- The Diagnostics Tool can be used to run tests on the HyperFabric adapter; the tool reports any failures.

You can run STM in three ways:

- In the X Windows environment.
- In command line mode.
- In menu mode.

See the *Support Media User's Manual* for details about using STM.

## Useful Files

When you are troubleshooting HyperFabric-related problems, you might find it useful to look at the contents of the following files:

- `/etc/rc.config.d/clic_global_conf`

This is the global configuration file. Check it to confirm that the configuration information is correct.

- `/var/adm/clic_log`

This is a global log file that contains a history of significant HyperFabric events. For example, it contains a history of the fabric's startup and any errors that occurred during it.

- `/var/adm/clic_log.old`

This is the backup copy of the log file that is created when the log file grows larger than 100 Kbytes

- `/var/adm/OLDclic_log`

This is the log file from the previous time the `clic_start` command was executed.

- `/var/adm/syslog.log`

This is the system log file, which contains a history of events occurring on the HP 9000 system.

- `/var/adm/clic_ip_drv.trc`

This is one of the HyperFabric software's trace files, and it is created by the `clic_diag -D TCP_IP` command.

- `/var/adm/clic_ip_drv.trc0`

This is one of the HyperFabric software's trace files, and it is the primary file created by the `clic_diag -C TCP_IP` command.

- `/var/adm/clic_ip_drv.trc1`

This is one of the HyperFabric software's trace files, and it is created by the `clic_diag -C TCP_IP` command when the primary trace file (`clic_ip_drv.trc0`) becomes full.

`/var/adm/clic_fw.dumpx`

This is the default file for a memory dump of an HyperFabric adapter, created when the `clic_diag -d` command is run without specifying an output file.

- `/etc/rc.config.d/netconf`

This file contains IP-related configuration information for all of the networking adapters installed in the HP 9000.

**IMPORTANT:** `clic_init` and SAM modify this file, adding some HyperFabric-related lines that end with the characters `#clic`. These lines are used by the HyperFabric software—and are not comments—so do not remove them from the file.

- `/etc/services`

This is the system service name database.

**IMPORTANT:** These two HyperFabric-related lines must be in this file:

— `hp-clic 3384/tcp #clic management daemon`

— `hp-clic 3384/udp #clic switch management`

These lines are used by the HyperFabric software—and are not comments—so do not remove them from the file.

## LED Colors and Their Meanings

Listed below are the possible colors (and the corresponding meaning) of the LEDs on the HyperFabric adapters and switches.

### Adapter LEDs

Table 5-1 below shows the names of the LEDs on each HyperFabric adapter. Note that the LEDs on the A4920A adapter are labeled, but the labels might be hard to see when a cable is connected to the adapter.

**Table 5-1 LED Names (by Adapter)**

| LED Name                 | HyperFabric Adapter |
|--------------------------|---------------------|
| "Connected/Traffic"      | A4919A              |
|                          | A6092A              |
| "Link"                   | A4920A              |
|                          | A6386A              |
| "Link Connected/Traffic" | A4921A              |
| "Error"                  | All                 |

Some of the LEDs—"Connected/Traffic," "Link," and "Link Connected/Traffic"—are equivalent but are labeled differently, depending on the adapter. So, their colors and meanings are the same, regardless of the adapter.

The HyperFabric adapter LED colors and meanings are as follows:

- ✓ If the adapter is not operational, the "Connected/Traffic," "Link," or "Link Connected/Traffic" LED on the adapter is off. Some of the possible reasons for this happening are the following:
  - The HP 9000 is not operational.
  - HyperFabric has not been started on the HP 9000.
  - An adapter is installed in a slot in the HP 9000, but the cable is attached incorrectly or no cable is attached at all.
  - The adapter is bad.
  - The cable is bad.
  - The switch port is bad (if the adapter is connected to a switch). Note that if a switch port is bad, and (for some reason) you cannot use a different port on the switch, you must replace (1) the entire HF1 switch, or (2) replace the switch module in the HF2 switch (whichever is applicable). However, you first should try turning the switch's power off and then back on.

- The adapter is connected to a non-operational adapter in the remote node (in a node-to-node configuration).
- ✓ If the connection from the adapter to the corresponding switch port (if a switch is used) or the corresponding adapter in the remote node (in a node-to-node configuration) is operational, the “Connected/Traffic,” “Link,” or “Link Connected/Traffic” LED on the adapter shows as solid green.
- ✓ If data is flowing between the adapter and the switch port (if a switch is used) or the corresponding adapter in the remote node (in a node-to-node configuration), the “Connected/Traffic,” “Link,” or “Link Connected/Traffic” LED shows as flashing green. Note that data does not start to flow until HyperFabric initialization has occurred (see “Using the clic\_init Command” on page 92).
- ✓ If the adapter is in an error state that requires it to be replaced, the “Error” LED on the adapter shows as solid yellow. See “Replacing a HyperFabric Adapter” on page 125 if you need to replace an adapter.

Table 5-2 below summarizes the adapter LED information in a table format.



**Table 5-2 HyperFabric Adapter LED Colors and Meanings**

| LED                                                                                                                                          | Color          | Meaning                                                                    | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------------------------|----------------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Connected/Traffic" (A4919A and A6092A adapters)<br><br>"Link" (A4920A and A6386A adapters)<br><br>"Link Connected/Traffic" (A4921A adapter) | None           | Adapter is not operational.                                                | <ul style="list-style-type: none"> <li>HP 9000 is not operational.</li> <li>HyperFabric is not running on HP 9000.</li> <li>Adapter is installed in a slot in HP 9000, but cable is attached incorrectly or no cable is attached at all.</li> <li>Adapter is bad.</li> <li>Cable is bad.</li> <li>Switch port is bad (if adapter is connected to a switch). If switch port is bad and you cannot use a different port on the switch, you must replace the entire HF1 switch or HF2 switch module. (First try powering the switch off and then back on.)</li> <li>Adapter is connected to a non-operational adapter in the remote node (in a node-to-node configuration).</li> </ul> |
|                                                                                                                                              | Solid green    | Connection from adapter to switch port or remote adapter is operational.   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|                                                                                                                                              | Flashing green | Data is flowing between the adapter and the switch port or remote adapter. | Data does not start to flow until HyperFabric initialization has occurred.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| "Error"                                                                                                                                      | None           | Adapter is not in an error condition.                                      | Adapter should be operating normally.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|                                                                                                                                              | Solid yellow   | Adapter is in an error condition.                                          | You must replace the adapter.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

## HF1 Switch LEDs

The HF1 switch LED colors and meanings are explained below.

- ❑ For each port on the switch:
  - ✓ If the port is not operational, the LED is off. *Some* of the possible reasons for this happening are the following:
    - A cable is not attached correctly to the port or no cable is attached at all.
    - The switch port is connected to a non-operational adapter in an HP 9000. (See “Adapter LEDs” on page 111 or Table 5-2 on page 113 for some tips about a non-operational adapter.)
    - The cable is bad.
    - The switch port is bad. Note that if a switch port is bad, and (for some reason) you cannot use a different port on the switch, you must replace the entire switch. However, you first should try turning the switch’s power off and then back on.
  - ✓ If the connection from the port to the corresponding adapter in the HP 9000 is operational, the LED on the port shows as solid green.
  - ✓ If data is flowing between the port and the corresponding adapter, the LED shows as flashing green. Note that data does not start to flow until HyperFabric initialization has occurred (see “Using the clic\_init Command” on page 92).

Note that each port and its LED are labeled with the port number (“0” through “15”), but not with the name of the LED (unlike the adapter’s LEDs, which might have an individual, specific label for each LED [for example, “Connected/Traffic”]). However, a legend listing the possible port states—disconnected, connected, and traffic flowing—and the corresponding LED colors is printed on a label on the back of the switch, for your reference.

- ❑ For the “Power” LED on the switch:
  - ✓ If the power to the switch is off, the LED is off.
  - ✓ If the power to the switch is on, the LED shows as solid green.

- ❑ For the “Ethernet” port and LED on the switch:
  - ✓ If the Ethernet port is not connected to the Ethernet network, the LED is off.
  - ✓ If the connection from the Ethernet port to the Ethernet network is operational, the LED on the port shows as solid green.
  - ✓ If data is flowing between the Ethernet port and the Ethernet network, the LED shows as flashing green.

Table 5-3 below summarizes the HF1 switch LED information in a table format.

**Table 5-3 HF1 Switch LED Colors and Meanings**

| LED     | Color          | Meaning                                           | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------|----------------|---------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Port    | None           | Port is not operational.                          | <ul style="list-style-type: none"> <li>A cable is not attached correctly to the port or no cable is attached at all.</li> <li>The switch port is connected to a non-operational adapter in an HP 9000. (See “Adapter LEDs” on page 111 or Table 5-2 on page 113 for some tips about a non-operational adapter.)</li> <li>The cable is bad.</li> <li>The switch port is bad. Note that if a switch port is bad, and (for some reason) you cannot use a different port on the switch, you must replace the entire switch. (First, try powering the switch off and then back on.)</li> </ul> |
|         | Solid green    | Connection from port to adapter is operational.   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|         | Flashing green | Data is flowing between the port and the adapter. | Data does not start to flow until HyperFabric initialization has occurred.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| “Power” | None           | Power to switch is off.                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|         | Solid green    | Power to switch is on.                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

**Table 5-3 HF1 Switch LED Colors and Meanings (Continued)**

| LED        | Color          | Meaning                                                               | Notes                                                                                                                                                                                                              |
|------------|----------------|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Ethernet" | None           | Ethernet port is disconnected.                                        | This can happen if the Ethernet port is not correctly connected to the Ethernet network. Management is disabled when the Ethernet port is not operating, however, this does not prevent the fabric from operating. |
|            | Solid green    | Connection from Ethernet port to the Ethernet network is operational. |                                                                                                                                                                                                                    |
|            | Flashing green | Data is flowing between the Ethernet port and the Ethernet network.   |                                                                                                                                                                                                                    |

## HF2 Switch LEDs

The HF2 switch LED colors and meanings are explained below.

- ❑ For each “Status” LED on the switch:
  - ✓ If the card/switch module is not operating, the LED is off.
    - For the integrated Ethernet management LAN adapter card (in the top slot) and the integrated 8-port fibre card (in the middle slot): the card can be safely removed by qualified Hewlett-Packard personnel only.
    - For an A6388A HF2 8-port fibre or A6389A HF2 4-port copper switch module in the expansion slot (the bottom slot): the switch module can be safely removed by you or qualified Hewlett-Packard personnel.
  - ✓ If a fault is occurring on the card/switch module, the LED shows as solid yellow.
  - ✓ If the card/switch module passed the self-test and is operating, the LED shows as solid green.
- ❑ For the “Power A” and “Power B” LEDs on the switch:
  - ✓ If the power to the switch is off, the LEDs are off.
  - ✓ If the power to the two redundant power buses is on, the LEDs show as solid green.

Note that if only one of the “Power” LEDs shows as solid green, the switch is still operational.
- ❑ For the “Ethernet Port Main” and “Ethernet Port Aux” LEDs on the switch:
  - ✓ If the associated Ethernet port is not connected to the Ethernet network, the LED is off.
  - ✓ If the connection from the associated Ethernet port to the Ethernet network is operational, the LED shows as solid green.
  - ✓ If data is flowing between the associated Ethernet port and the Ethernet network, the LED shows as flashing green.

- ❑ For each port on the cards/switch module in the switch:
  - ✓ If the port is not operational, the LED is off. Some of the possible reasons for this happening are the following:
    - A cable is not attached correctly to the port or no cable is attached at all.
    - The port is connected to a non-operational adapter in an HP 9000. (See “Adapter LEDs” on page 111 or Table 5-2 on page 113 for some tips about a non-operational adapter.)
    - The cable is bad.
    - The port is bad. Note that if a port is bad, and (for some reason) you cannot use a different port on that card/switch module, you can replace the card/switch module. Remember, though, that the integrated 8-port fibre card can be removed by qualified Hewlett-Packard personnel only. The A6388A and A6389A switch modules can be removed by you or qualified Hewlett-Packard personnel. However, you first should try turning the switch's power off and then back on.
  - ✓ If the connection from the port to the corresponding adapter in the HP 9000 is operational, the LED on the port shows as solid green.
  - ✓ If data is flowing between the port and the corresponding adapter, the LED shows as flashing green. Note that data does not start to flow until HyperFabric initialization has occurred (see “Using the clic\_init Command” on page 92).

Note that a legend listing the possible port states—disconnected, connected, and traffic—and the corresponding LED colors is printed on the front of the switch, for your reference.

Table 5-4 below summarizes the HF2 switch LED information in a table format.

**Table 5-4 HF2 Switch LED Colors and Meanings**

| LED                                          | Color          | Meaning                                                                   | Notes                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------|----------------|---------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Status"                                     | None           | The card/switch module is not operating.                                  | Integrated Ethernet management LAN adapter card (in the top slot) & integrated 8-port fibre card (in the middle slot): the card can be safely removed by qualified Hewlett-Packard personnel only. A6388A HF2 8-port fibre or A6389A HF2 4-port copper switch module in the expansion slot (the bottom slot): the switch module can be safely removed by you or qualified Hewlett-Packard personnel. |
|                                              | Solid yellow   | A fault is occurring on the card/switch module.                           |                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                              | Solid green    | The card/switch module passed the self-test and is operating.             |                                                                                                                                                                                                                                                                                                                                                                                                      |
| "Power A" and "Power B"                      | None           | Power to switch is off.                                                   |                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                              | Solid green    | Power to switch is on.                                                    | One LED solid green: switch is still operational.                                                                                                                                                                                                                                                                                                                                                    |
| "Ethernet Port Main" and "Ethernet Port Aux" | None           | Ethernet port is disconnected.                                            | This can happen if the Ethernet port is not correctly connected to the Ethernet network, or the integrated Ethernet management LAN adapter card is experiencing a fault. Management is disabled when the Ethernet port is not operating, however, this does not prevent the fabric from operating.                                                                                                   |
|                                              | Solid green    | Connection from the Ethernet port to the Ethernet network is operational. |                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                              | Flashing green | Data is flowing between the Ethernet port and the Ethernet network.       |                                                                                                                                                                                                                                                                                                                                                                                                      |



**Table 5-4 HF2 Switch LED Colors and Meanings (Continued)**

| LED      | Color          | Meaning                                           | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|----------------|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Port x" | None           | Port is not operational.                          | <ul style="list-style-type: none"> <li>A cable is not attached correctly to the port or no cable is attached at all.</li> <li>The port is connected to a non-operational adapter in an HP 9000. (See "Adapter LEDs" on page 111 or Table 5-2 on page 113 for some tips about a non-operational adapter.)</li> <li>The cable is bad.</li> <li>The port is bad. Note that if a port is bad, and (for some reason) you cannot use a different port on that card/switch module, you can replace the card/switch module. The integrated 8-port fibre card (in the middle slot): the card can be safely removed by qualified Hewlett-Packard personnel only. A6388A HF2 8-port fibre or A6389A HF2 4-port copper switch module in the expansion slot (the bottom slot): the switch module can be safely removed by you or qualified Hewlett-Packard personnel. First, try powering the switch off and then back on.</li> </ul> |
|          | Solid green    | Connection from port to adapter is operational.   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|          | Flashing green | Data is flowing between the port and the adapter. | Data does not start to flow until HyperFabric initialization has occurred.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

---

## Determining Whether an Adapter or a Cable is Faulty

If you suspect that either an HyperFabric adapter or a cable attached to it is faulty, follow these steps to determine which component needs replacing:

**Step 1.** Disconnect the cable from the HyperFabric adapter.

**Step 2.** Attach a loopback plug to the adapter:

- For the A4919A, A4920A, A4921A, and A6092A adapters: Be sure to use a copper loopback plug (one is shipped with each HF1 adapter).
- For the A6386A adapter: Be sure to use a fibre loopback plug (one [HP part number A6384-67004] is shipped with each HF2 switch).

**Step 3.** Determine if the adapter is faulty:

- If the adapter is functioning correctly, the “Connected/Traffic,” “Link,” or “Link Connected/Traffic” LED on the adapter shows as solid green.
- If the adapter is faulty, the “Error” LED on the adapter shows as solid yellow.

See Table 5-1 on page 111 for a list of the LED names for each HyperFabric adapter.

**Step 4.** If the adapter is faulty, you must replace it (see “Replacing a HyperFabric Adapter” on page 125).

If the adapter is not faulty, assume that the cable is faulty and you must replace it.

---

## Determining Whether a Switch is Faulty

If you suspect that a HyperFabric switch is faulty, follow the steps below to determine if the switch needs replacing.

### HF1 Switch

The steps for determining if an HF1 switch is faulty are as follows:

- Step 1.** Disconnect the cable from the switch port you suspect is faulty.
- Step 2.** Attach a copper loopback plug to the relevant port. A copper loopback plug is shipped with each HF1 adapter (not with the HF1 switch).
- Step 3.** Determine if the port is faulty:
- If the port is functioning correctly, the port's LED shows as solid or blinking green.
  - If the port is faulty, the port's LED is off.

Repeat Steps 1 through 3 for all ports on the switch, to determine if any of them are faulty.

- Step 4.** If any one of the ports on the switch is faulty, do not use it. Use a known good port if one is available. If no good ports are available, you must replace the switch. (See “Replacing a HyperFabric Switch” on page 126.)

### HF2 Switch

The steps for determining if an HF2 switch is faulty are as follows:

- Step 1.** Check the cards/switch module in the switch—the integrated Ethernet management LAN adapter card, integrated 8-port fibre card, and switch module in the expansion slot:
- a. If the card/switch module is functioning correctly, its “Operating/Fault” LED shows as solid green.
  - b. If the card/switch module is experiencing a fault, its “Operating/Fault” LED shows as solid yellow.
  - c. If the card/switch module is not operating, its “Operating/Fault” LED is off.
- Step 2.** Check the switch's power:
- a. If the power to the switch is on, the “Power A” and “Power B” LEDs both show as solid green.
  - b. If only one of the “Power” LEDs shows as solid green, the switch is still operational. However, the integrated Ethernet management LAN adapter card should be replaced soon. (Remember, it can be replaced by qualified Hewlett-Packard personnel only.)
  - c. If both “Power” LEDs are off, the enclosure (the power supply, backplane, and fan-monitoring board) must be replaced by qualified Hewlett-Packard personnel only.
- Step 3.** Check the switch's Ethernet ports:

- a. If the port is connected to an operational Ethernet network, the port's LED ("Ethernet Port Main" or "Ethernet Port Aux") shows as solid or blinking green.
- b. If the port is disconnected, or connected to an Ethernet network that is not operational, the port's LED is off.

**Step 4.** Check the ports on the cards/switch module:

- a. Disconnect the cable from the card/switch module port you suspect is faulty.
- b. Attach a loopback plug to the relevant port:
  - If the port is on the integrated 8-port fibre card or the A6388A HF2 8-port fibre switch module in the expansion slot, use a fibre loopback plug. (A fibre loopback plug [HP part number A6384-67004] is shipped with each HF2 switch).
  - If the port is on the A6389A HF2 4-port copper switch module in the expansion slot, use a copper loopback plug (one is shipped with each HF1 adapter).
- c. Determine if the port is faulty:
  - If the port is functioning correctly, the "Port x" LED shows as solid or blinking green.
  - If the port is faulty, the "Port x" LED is off.

Repeat steps a through c for each port on the cards/switch module, to determine if any of them are faulty.

- d. If the port is faulty, do not use it. Instead, use a known good port on that card/switch module if one is available. If no good ports are available, replace that card/switch module. Remember, though, that the integrated 8-port fibre card can be removed by qualified Hewlett-Packard personnel only. The A6388A and A6389A switch modules can be removed by you or qualified Hewlett-Packard personnel.

**Step 5.** If a fan is not running, the fan tray must be replaced by qualified Hewlett-Packard personnel only.

---

## Replacing a HyperFabric Adapter

If OLAR is supported for the HP 9000 system and the HyperFabric adapter, and you want to do OLR, see “Online Replacement (OLR)” on page 58. The *HP HyperFabric Release Note* contains information about which HP 9000 systems and HyperFabric adapters OLAR is supported for.

If you cannot or do not want to do OLR to replace a HyperFabric adapter, follow these steps:

- Step 1.** Stop HyperFabric on the node where the faulty adapter is installed (see “Stopping HyperFabric” on page 99).
- Step 2.** Depending on the type of HP 9000 the adapter is in, follow the steps in the HP 9000’s documentation for installing the adapter.

---

### WARNING

**User Note: V-Class installation must be done by a Hewlett-Packard Customer Engineer qualified in installing and servicing the HP V-Class system and trained to recognize the hazards involved. The I/O board is installed in an area of the V-Class where hazardous energy levels might be produced. Any attempt by non-HP personnel to install a HyperFabric adapter in a V-Class system might result in a void of warranty.**

**Customer Engineer Note: You might want to refer to the V-Class system’s documentation to identify various areas of the V-Class card cage. The PCI HyperFabric adapters are installed in one of the V-Class’s Exemplar I/O boards. Only one HyperFabric adapter per V-Class SAGA/EPIC is supported.**

---

Remember that, when you replace a HyperFabric adapter, you do not have to re-install the HyperFabric software.

- Step 3.** Start HyperFabric on the HP 9000 (see “Starting HyperFabric” on page 85).

## Replacing a HyperFabric Switch

If you need to replace a faulty HyperFabric switch, follow these steps:

- Step 1.** If you do not have an HA environment, stop HyperFabric on all nodes that are connected to the faulty switch. (See “Stopping HyperFabric” on page 99.)

If you have an HA environment with two switches (where the backup switch will have taken over when the first switch failed), disconnect all cables attached to the faulty switch.

- Step 2.** Install a new switch. (See “Installing HyperFabric Switches” on page 66.)

- Step 3.** If you stopped HyperFabric on all nodes connected to the switch (in step 1), start it on those nodes. (See “Starting HyperFabric” on page 85.)

---

## **Index**

### **A**

- adapters
  - deconfiguring, 96
  - faulty, testing for, 146
  - installing, 54
  - LED colors and meanings, 135, 137
  - OLA of, 57
  - OLR of, 58

replacing, 149

## C

cables, testing for faulty, 146

CLIC, definition of, 19, 60

clac\_diag command, 113, 129

clac\_init command, 92  
after OLA, 58

clac\_ping command, 111

clac\_probe command, 111  
to remote node, 130

clac\_shutdown command, 123

clac\_start command, 109  
after OLA, 58

clac\_stat command, 115

CLuster InterConnect. *See* CLIC

commands

clac\_diag, 113, 129

clac\_init, 92  
after OLA, 58

clac\_ping, 111

clac\_probe, 111  
to remote node, 130

clac\_shutdown, 123

clac\_start, 109  
after OLA, 58

clac\_stat, 115  
viewing man pages, 122

communications within fabric, verifying, 111

concepts, 19

configuration

clac\_init command, 92  
after OLA, 58

global file  
contents of, 85  
creating, 91

HA, description of, 19

information

example of, 88  
needed for, 86

overview of, 85  
typical, description of, 19  
using SAM, 94

## D

deconfiguring an adapter, 96

definitions

fabric, 19

HA, 19

management process, 19

diagnostics, running, 129

displaying

statistics, 115  
status, 115

## F

fabric

communications within, verifying, 111



- current map of, 115, 116
- definition of, 19
- planning, 23

#### files

- global configuration
  - contents of, 85
  - creating, 91
- software
  - description of, 60
  - structure of, 60

## H

### HA

- configuration, description of, 19
- definition of, 19
- MC/ServiceGuard and HyperFabric, 98

High Availability. *See* HA

## I

### installation

- adapters, 54
- prerequisites for, 53
- software, 60
  - steps for, 64
- switch, 66
  - HF2, 76
  - steps for HF, 68
  - steps for HF2, no rail kit, 81

IP addresses, relocatable. *See* relocatable IP addresses.

## L

### LEDs

- colors and meanings
  - for adapters, 135, 137
  - for HF switches, 138, 140
  - for HF2 switches, 142, 145
- on HF switches, 68
- on HF2 switches, 76, 77

## M

- man pages, viewing, 122
- management process, definition of, 19
- MC/ServiceGuard
  - configuring, 98
  - handling adapter failures, 100

## O

### OLAR

- adapter compatibility, OLA, 57
- adapter compatibility, OLR, 58
- checking critical resources, 57
- planning and preparation for, 57
- terminology, 56

overview

- of configuration, 85

## **P**

- planning the fabric, 23
- prerequisites for installation, 53

## **R**

- relocatable IP addresses, 19
  - configuring, 106

## **S**

### **SAM**

- using for configuration, 94
- using for deconfiguring an adapter, 96
- using for starting HyperFabric, 110
- using for stopping HyperFabric, 124

### **software**

- file structure, 60
- files, description of, 60
- installing, 60
  - steps for, 64

### **starting HyperFabric**

- after OLA, 58
- using clic\_start, 109
- using SAM, 110

- statistics, displaying, 115

### **status**

- displaying, 115
- of one switch, 116

- STM tools for HyperFabric, 132

### **stopping HyperFabric**

- using clic\_shutdown, 123
- using SAM, 124

- Support Tools Manager. *See* STM

### **switches**

- installing, 66
  - HF2, 76
  - steps for HF, 68
  - steps for HF2, no rail kit, 81

### **LEDs**

- colors and meanings for HF, 138, 140
- colors and meanings for HF2, 142, 145
- location of for HF, 68
- location of for HF2, 76, 77

- replacing, 150

### **status**

- of one, 116
- testing for faulty, HF, 147
- testing for faulty, HF2, 147

## **T**

### **tracing**

- data
  - dumping, 130
  - formatting, 130
- level, for drivers, 130

## **V**

- verifying communications within fabric, 111

viewing man pages, 122  
VRID, 86

